OSCILLOSCOPE 120B



HEWLETT hp PACKARD

CERTIFICATION

The Hewlett-Packard Company certifies that this instrument was thoroughly tested and inspected and found to meet its published specifications when it was shipped from the factory. The Hewlett-Packard Company further certifies that its calibration measurements are traceable to the U.S. National Bureau of Standards to the extent allowed by the Bureau's calibration facility.

WARRANTY AND ASSISTANCE

All Hewlett-Packard products are warranted against defects in materials and workmanship. This warranty applies for one year from the date of delivery, or, in the case of certain major components listed in the operating manual, for the specified period. We will repair or replace products which prove to be defective during the warranty period provided they are returned to Hewlett-Packard. No other warranty is expressed or implied. We are not liable for consequential damages.

Service contracts or customer assistance agreements are available for Hewlett-Packard products that require maintenance and repair on-site.

For any assistance, contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided at the back of this manual.

MODEL 120B

OSCILLOSCOPE

Manual Serials Prefixed: 601— Manual Printed: NOV 1966

Make all changes in this manual according to the Errata below. Also check the following table for your instrument serial prefix (3 digits) and/or serial number (8 digits) and make any listed change(s) in the manual:

Serial Prefix or Number Make Manual Changes		Serial Prefix or Number Make Manual Changes
915-	None	
959	None	
		1208

ERRATA

Page 5-17, Figure 5-8,

R204: Change value to 1800 ohms, and delete asterisk.

Page 5-18, Figure 5-9,

V308: Change tube type to 6GH8A.

Page 5-19, Figure 5-10,

Add attached Figure 5-9A.

△ R303: Change value to 100 k ohms.

Table 6-2,

A301: Change HP Part No. to 120B-65H.

C8, C15, C102, C304, C306: Change to HP Part No. 0160-2902; same description; Mfr 56289; Mfr Part No. 29C214A3CDH. (Preferred replacement.)

C14: Change to HP Part No. 0160-2983; same description, Mfr and Mfr Part No. (Preferred Replacement.)

C211, C301, C311: Change to HP Part No. 0160-2897; same description;

Mfr 05447; Mfr Part No. Type 126. (Preferred replacement.)

C213, C323, C326, C329: Change to HP Part No. 0160-2897; same description; Mfr 71590; Mfr Part No. DD203. (Preferred replacement.)

R204: Change to HP Part No. 0758-0043; R: fxd metox 1800 ohms 5% 1/2 W;

Mfr HP. (Preferred replacement.)

Option 05: Change HP Part No. for lamp holder to 1450-0154.

Option 06:

Change HP Part No. for 3-pin female connector to 1250-0038.

Add: HP Part No. 1251-0039; TQ 2; Connector: 3 contact male; Mfr 71468; Mfr Part No. CA3102A10SL-3P-A105.

Change HP Part No. for cable clamp to 1251-0040.

Option 13: Change HP Part No. 120B-5B to 120B-5C.

△ R303: Change to HP Part No. 0693-1041; R: fxd composition 100 k ohms 2 W. (Preferred replacement.)

This change sheet supersedes all prior change sheets for this manual.

Instrument Serial P	refix	

36.1	**1	01
Make	Manua	Changes

T	 L C '	Profix

Make Manual Changes

915-	None	1000
959—	None	The same of the sa




Figure 5-9A. High-Voltage Supply Component Identification.

^{*}Signifies a (9) wire.



OPERATING AND SERVICE MANUAL

MODEL 120B OSCILLOSCOPE

SERIALS PREFIXED: 601-

(For Instruments With Other Serial Prefixes, See Section I and Appendix I)

Copyright HEWLETT-PACKARD COMPANY/COLORADO SPRINGS DIVISION 1965
1900 GARDEN OF THE GODS ROAD, COLORADO SPRINGS, COLORADO, U. S. A.

01260-4

PRINTED: NOV 1966

TABLE OF CONTENTS

Sec	tion	Pa	age Se	ction		Page
I	GENE	RAL INFORMATION1-	1 V	MAIN	TENANCE	. 5-1
	1-1. 1-4. 1-14. 1-16.	Introduction. 1- Description. 1- Cathode Ray Tube Warranty 1- Options	1 2	5-1. 5-3. 5-5. 5-7.	Introduction. Test Equipment Troubleshooting System Troubleshooting	. 5-1 . 5-1
п	INSTA	LLATION2-	1	5-9. 5-14.	Sectional Troubleshooting High-Voltage Power Supply	. 5-2
	2-1. 2-7. 2-10. 2-13.	Incoming Inspection 2- Power Requirements 2- Installation 2- Repackaging for Shipment 2-	·1 ·2	5-16. 5-17. 5-19. 5-21. 5-23.	Repair . Replacement of Semiconductors Servicing Etched Circuit Boards Crt Replacement . Adjustments	. 5-5 . 5-5 . 5-5
ш	OPER.	ATION	1	5-24. 5-27.	Adjustments Following Repair Low-Voltage Power Supply	
	3-1. 3-3. 3-5.	Introduction	1	5-33. 5-35. 5-42. 5-48.	High-Voltage Power Supply Vertical Amplifier Horizontal Amplifier Sweep Generator	. 5-6 . 5-9 . 5-10 . 5-11
IV	PRINC	CIPLES OF OPERATION 4-	1	5-52. 5-67.	Performance Check	
	4-1. 4-9.	Overall Block-Diagram Description. 4-Circuit Analysis 4-	9		Diagrams	
	4-10.	Vertical Amplifier 4-	2		ACEABLE PARTS	6-1
	4-16. 4-30. 4-34.	Sweep Generator 4- Horizontal Amplifier 4- Low-Voltage Power Supply 4-	4	6-1. 6-4.	Introduction Ordering Information	
	4-41.	High-Voltage Power Supply 4-	6 AP	PENDIX	I	IA-1

ii

LIST OF ILLUSTRATIONS

Number	r Title Page	Numbe	r Title P	age
1-1. 2-1.	Model 120B Oscilloscope 1-1 Primary-Power Connections 2-1	5-1.	Top View, Location of Parts and Adjustments 5	-3
2-2.	Rack Mounting 2-2	5-2.	High-Voltage Power Supply, Location	
3-1. 3-2.	Model 120B Oscilloscope, Front View 3-2 Operation Using Internal Horizontal Sweep or Single Sweep 3-3	5-3.	of Parts	
3-3.	Operation Using External Horizontal Input	5-4.	Parts and Adjustments 5. Right-Side View, Side Panel Removed, Location of Parts and Adjustments 5.	
3-4.	Operation Using Balanced Vertical	5-5.	Servicing Etched Circuit Boards 5	
3-5.	Input	5-6.	Vertical Amplifier, Schematic Diagram5	-15
	Balance Adjustment 3-6	5-7.	Horizontal Amplifier, Schematic Diagram5	-17
4-1.	Overall Block Diagram 4-1	5-8.	Sweep Generator, Schematic Diagram 5	-19
4-2. 4-3.	Sweep Generator, Block Diagram 4-2	5-9.	Low-Voltage Power Supply, Schematic Diagram	-21
4-4.	Sweep Generator Waveforms 4-3 Typical Schmitt Trigger 4-3	5-10.	High-Voltage Power Supply, Schematic Diagram5	-23
4-5.	Low-Voltage Power Supply, Block Diagram	5-11.	Horizontal Display Switch, Schematic	-25
4-6.	High-Voltage Power Supply, Block Diagram 4-6	6-1.	Modular Cabinet Replaceable Parts 6	

LIST OF TABLES

Numbe	r Title	Page
1-1.	Specifications	1-0
5-1. 5-2. 5-3.	Recommended Test Equipment	
5-4. 5-5. 5-6.	Transistor, and Diode Replacement Low-Voltage Power Supply Voltages Horizontal Sweep-Time Adjustment Horizontal Sweep Time	5-9 5-12
6-1.	List of Reference Designators and Abbreviations	6-3
6-3.	Code List of Manufacturers	6-13

SWEEP

Sweep Range:

One $\mu sec/cm$ to at least 0.5 sec/cm. Fifteen calibrated sweeps accurate to within $\pm 5\%$, in a 1,2,5,10... sequence, from 5 $\mu sec/cm$ to 200 millisec/cm. Vernier control permits continuous adjustment of sweep time between calibrated steps, and extends the 200 millisec/cm to at least 0.5 sec/cm.

Sweep Expand:

X5 sweep expansion may be used on all ranges and expands fastest sweep to 1 $\mu sec/cm$. Expanded sweep accuracy is $\pm 10\%$.

Automatic Synchronization:

Internal: from signals 50 cps to 450 kc with approximately 0.5-cm or more vertical deflection; and from line voltage.

External: from signal 50 cps to $450 \ kc$, $1.5 \ v$ peak-to-peak.

Trigger Point:

Zero-crossing negative slope of external sync signals; or zero-crossing positive or negative slope of vertical deflection signals. Front-panel control overrides automatic and permits the trigger point to be set between -7 to +7 volts. Turning control fully counterclockwise restores automatic operation.

VERTICAL AMPLIFIER

Bandwidth:

DC coupled: dc to 450 kc. AC coupled: 2 cps to 450 kc. Bandwidth is at least 450 kc regardless of sensitivity setting.

Sensitivity:

10 millivolts/cm to 100 volts/cm. Four calibrated steps with attenuator accuracy of $\pm 3\%,$ 10 mv/cm, 100 mv/cm, 1 v/cm, and 10 v/cm. Vernier permits continuous adjustment of sensitivity between steps, and extends 10 v/cm step to at least 100 v/cm.

Internal Calibrator:

Calibrating signal automatically connected to vertical amplifier for standardizing of gain, accuracy $\pm 2\%.$

Input Impedance:

1 megohm, shunted by approximately 50 pf.

Balanced Input:

On 10 mv/cm range only; input impedance is 2 megohms shunted by approximately 25 pf.

Common-Mode Rejection:

Rejection at least 40 db. Common mode signal must not exceed ± 3 volts peak.

Phase Shift:

Vertical and horizontal amplifiers have same phase characteristics within $\pm 2^{\circ}$ to 100 kc when verniers are in CAL.

HORIZONTAL AMPLIFIER

Bandwidth:

DC coupled: dc to 300 kc. AC coupled: 2 cps to 300 kc. Bandwidth is at least 300 kc regardless of attenuator setting.

Sensitivity:

 $0.1~\rm volt/cm$ to $100~\rm volts/cm$. Three calibrated steps, accurate within $\pm 5\%,~0.1~\rm v/cm,~1~\rm v/cm,$ and $10~\rm v/cm$. Vernier permits continuous adjustment of sensitivity between steps and extends $10~\rm v/cm$ step to at least $100~\rm v/cm$.

Input Impedance:

1 megohm nominal, shunted by approximately 100 pf.

Phase Shift:

Horizontal and vertical amplifiers have same phase characteristics within $\pm 2^{\circ}$ to 100 kc when verniers are in CAL.

GENERAL

Cathode Ray Tube:

P31 phosphor, mono-accelerator with internal graticule normally supplied; 2700-volt accelerating potential. Face plate eliminates glare and reduces hazard of implosion. P2, P7, and P11 phosphors also available.

Internal Graticule:

10 cm x 10 cm marked in cm squares. Major horizontal and vertical axes have 2-mm subdivisions. Eliminates parallax error.

Intensity Modulation:

Terminals on front panel. Plus 20 volt pulse required to blank trace of normal intensity.

Dimensions:

16-3/4 in. wide, 7-1/2 in. high, 18-3/8 in. deep, overall; hardware furnished for quick conversion to 7 in. x 19 in. rack mount.

Weight:

Net: 32 lbs; shipping 45 lbs.

Power:

115 or 230 volts $\pm 10\%$, 50 to 1000 cps, approximately 95 watts.

Options:

- 05. External graticule crt with P31 phosphor.
- 06. Rear terminals in parallel with front.
- 10. Provision for single sweep operation.
- 13. Special front panel for rack mounting only.

SECTION I GENERAL INFORMATION

1-1. INTRODUCTION.

- 1-2. This manual provides complete instructions on the installation, operation, theory of operation, and maintenance of the Hewlett-Packard Model 120B Oscilloscope.
- 1-3. The Hewlett-Packard Company uses a two-section, eight-digit serial number (e.g. 000-00000). If the serial prefix (first three digits) on your instrument does not agree with the prefix shown on the title page of this manual, refer to either the separate change sheet included or Appendix I, which contain changes required to adapt this manual to the listed prefixes. The separate change sheet also contains corrections required for all known errata (errors). Contact your Hewlett-Packard Sales/Service Office if additional information or clarification is required.

1-4. DESCRIPTION.

1-5. The Model 120B is a general-purpose oscilloscope whose bandwidth extends from dc to 450 kc. It combines the precision characteristics of calibrated

- horizontal sweeps, calibrated vertical sensitivity, and a crt that eliminates parallax error; in addition, its construction provides easy circuit accessibility and quick convertibility from a rack-mounting to a bench-model configuration. Specifications are listed in table 1-1.
- 1-6. The internal graticule of the Model 120B is in the same plane as the phosphor and crt trace; consequently, crt parallax error is avoided, allowing easier, quicker, and more accurate measurements.
- 1-7. The Model 120B can be used with either internal or external sweeps, which can be either internally or externally synchronized. Because of its high sensitivity and balanced input, the Model 120B can be used to view complex waveforms and monitor transducer outputs.
- 1-8. Computations are avoided and possibilities of error are reduced by direct-reading calibrated sweeps. A single control selects 1 of 15 calibrated sweeps between the ranges of 5 microseconds/cm and 200



Figure 1-1. Model 120B Oscilloscope

01260-3

milliseconds/cm or determines the calibrated sensitivity of the horizontal amplifier. Continuous control of sweep time and horizontal sensitivity between calibrated steps is provided by a vernier control; the vernier control extends the 200 milliseconds/cm sweep time to at least 0.5 seconds/cm, and reduces the horizontal amplifier sensitivity to at least 100 volts/cm.

- 1-9. Accurate direct-reading sweeps are obtained from a feedback type (Miller) integrator, which ensures high linearity and stability of the horizontal sweep. This type of sweep generator is reliable and relatively independent of vacuum—tube characteristics.
- 1-10. Observation and analysis of transients are simplified by the expanded-sweep control. This X5 sweep expander may be used on all sweep time settings, and expands the fastest sweep time to 1 microsecond/cm.
- 1-11. An automatic trigger capability facilitates establishing a base line on the crt when a synchronizing signal is not present. The automatic baseline provision can be easily locked-out and an adjustable trigger level established.
- 1-12. Accurate voltage measurements of waveforms are quickly made with the Model 120B. A built-in calibrator that is accurate to within ± 2 percent permits rapid verification and standardization of vertical amplifier sensitivity.
- 1-13. Phase-shift measurements can be made accurately over a wide range of input frequencies. Relative phase shift between the vertical and horizontal amplifiers is less than 2 degrees up to 100 kc.

1-14. CATHODE RAY TUBE WARRANTY.

1-15. The cathode ray tube supplied with the Model 120B and replacement crt's purchased from Hewlett-Packard Company are guaranteed against electrical failure for one year from the date of sale by Hewlett-Packard. The Cathode Ray Tube Warranty and Claim sheet is included at the rear of this manual.

1-16. OPTIONS.

- 1-17. The Model 120B is available with four options, as listed in table 1-1. Replaceable parts for all options are listed under MISCELLANEOUS at the end of table 6-1.
- 1-18. OPTION 05. This option provides a crt without internal graticule. An external graticule with adjustable illumination is installed over the face of the crt. Refer to figure 5-9 for a schematic of the added circuit. CRT's without internal graticule are available with types P7, P11, and P31 phosphor. A filter is also supplied with each crt; amber for P7 type, blue for P11 type, and green for P31 type.

- 1-19. OPTION 06. This option provides rear panel connectors in parallel with the front panel input connectors. One connector is wired in parallel with the VERTICAL input terminals on the front panel, and one connector is wired in parallel with the HORIZON-TAL input terminals as shown in figures 5-6 and 5-7. Mating connectors and cable clamps are also supplied. The additional circuitry changes the vertical input capacitance to approximately 75 pf, and the horizontal input capacitance to approximately 135 pf.
- 1-20. OPTION 10. This option provides circuitry for single sweep operation. Operation procedures are contained in figure 3-2 and a schematic for the added circuit is shown in figure 5-8.
- 1-21. OPTION 13. This option provides a plain $7 \times 9 \times 3/16$ inch front panel for rack mounting only. The panel is suitable for installing special handles to match existing equipment in system or console configuration.
- 1-22. AMBER FILTER. A special amber filter is supplied with oscilloscopes having an internal graticule crt with P7 phosphor. This filter may be installed for improved visual observation of displays such as single-shot phenomena or very low frequency applications. The filter will improve the long persistency characteristics desired for visual observations of this type display. To install the filter proceed as follows:
 - a. Remove front panel crt bezel.
- b. Set filter into bezel, aligning larger rectangular slots in the edge of filter with metal guide posts of the bezel casting.
- c. Remove oscilloscope top cover for access to rear of crt.
- d. Carefully move crt towardrear of instrument enough to provide clearance for thickness of installed filter (about 1/8 inch).
 - e. Loosen clamp at socket of crt.
- f. Replace bezel with filter and tighten bezel screws.
- g. Slide crt forward until light mask on front of crt just lightly touches filter.
- h. Tighten clamp just enough to keep crt from turning. Do not over-tighten the clamp or tube damage may result.
- i. Check alignment of trace with graticule according to the procedure given in Section V of this manual.

SECTION II

2-1. INCOMING INSPECTION.

- 2-2. MECHANICAL INSPECTION. Unpack and inspect the Model 120B in the presence of the carrier. Be careful when unpacking the instrument, for all electron tubes including the cathode ray tube remain installed during shipment. Save all packing materials until inspection is complete. These materials may be required for reshipment in the event shipping damage is discovered.
- 2-3. Inspect the instrument for signs of possible damage in shipment such as scratched panel, broken knobs, etc. If possible, energize the equipment and check it operationally (see paragraph 2-5).
- **2-4.** If there are any indications of damage, file a claim with the carrier. Refer to the Hewlett-Packard Warranty sheet at the front of this manual.
- 2-5. PERFORMANCE CHECK. Paragraph 5-52 contains performance check procedures for verifying operation within listed specifications. The performance check is recommended for inclusion in receiving quality-control inspection. The following procedure is offered, however, as a means to check basic operation.
- 2-6. INITIAL TURN ON. Energize the 120B as follows:
- a. Turn INTENSITY control to OFF and plug in power cable.
- b. Set SWEEP MAGNIFIER switch to X1 position.
- c. Set HORIZONTAL DISPLAY switch to 0.5 MILLISECONDS/CM position.
- d. Center HORIZONTAL POSITION and VERTICAL POSITION controls.
- e. Turn 120B on and allow two minutes warmup.
- f. Set TRIGGER LEVEL to AUTO.
- g. Rotate INTENSITY clockwise until trace appears. If crt remains blank, press BEAM FINDER and readjust position controls as necessary.
- h. Adjust FOCUS for thin, well-defined trace, and adjust HORIZONTAL POSITION to place left end of sweep on left-end graticule line.

2-7. POWER REQUIREMENTS.

2-8. The Model 120B requires a power source of 115 or 230 volts $\pm 10\%$, single phase, 50 to 1000 cps, which can deliver approximately 95 watts. The oscilloscope is normally shipped from the factory wired for use with a 115-volts power source. To convert the instrument for use with a 230-volt source, change the dual primary windings of transformer T302 from a parallel combination to a series combination. Figure 2-1 illustrates the connection for 115- and 230-volt operation. At the time of the change, replace the 1.6-ampere slow-blow line fuse with 0.8-ampere slow-blow fuse.




Figure 2-1. Primary-Power Connections

2-9. For the protection of operating personnel, the National Electrical Manufacturers' Assn (NEMA) recommends that the instrument panel and cabinet be grounded. This instrument is equipped with a three-conductor power cable which, when plugged into an appropriate receptacle, grounds the instrument. The offset pin on the power cable three-prong connector is the ground pin. To preserve the protection feature when operating the instrument from a two-contact outlet, use a three-prong to two-prong adapter and connect the green pigtail on the adapter to ground.




Figure 2-2. Rack Mounting

2-10. INSTALLATION.

2-11. MODULAR CABINET. The Model 120B Oscilloscope is shipped from the factory as a bench instrument with the tilt stand, feet and plastic trim in place. The top and bottom cabinet covers may be removed, giving complete accessibility to all components and adjustments. When used on the bench, other instruments may be stacked on the louver-free top surface; however, sufficient space should be allowed around the cabinet for adequate circulation of air.

2-12. RACK MOUNTING. Prepare the cabinet for rack mounting as illustrated in figure 2-2. The trim strip and rack-mounting flanges are in the shipping container with the instrument. After preparation, lift instrument into place and secure mounting flanges to rack with appropriate screws. Allow adequate ventilation for the instrument in the rack.

2-13. REPACKAGING FOR SHIPMENT.

2-14. The following list is a general guide for repackaging an instrument for shipment; however, if you have any questions, contact your authorized Hewlett-Packard sales representative.

- a. If possible, use original container designed for the instrument.
- b. Wrap instrument in heavy paper or plastic before placing it in shipping container.
- c. Use sufficient quantities of packing material around all sides of the instrument and protect panel with cardboard strips.
- d. Use heavy cardboard carton or wooden box to house the instrument and use heavy tape or metal bands to seal the container.
- e. Mark packing box with "Fragile", "Delicate Instrument", etc.

Note

If the instrument is to be shipped to Hewlett-Packard Company for service or repair, attach to the instrument a tag identifying the owner, the instrument's complete serial number, and the service or repair to be accomplished; in addition, notify Hewlett-Packard Company or a representative before shipping the instrument. In any correspondence, reference the instrument by model number and complete serial number.

SECTION III OPERATION

3-1. INTRODUCTION.

3-2. This section contains operating instructions for the Model 120B Oscilloscope. Included are descriptions of the Model 120B controls and indicators, and operation of the Model 120B as a general-purpose oscilloscope.

3-3. CONTROLS AND INDICATORS.

3-4. Figure 3-1 illustrates the controls and indicators along with a short description of the particular function of each.

3-5. GENERAL OPERATING SUGGESTIONS.

- **3-6.** The following paragraphs, 3-7 through 3-16, provide suggestions for expediting and simplifying operation of the Model 120B.
- 3-7. SYNCHRONIZING THE SWEEP. The horizontal sweep can be synchronized with the vertical input signal (INT positions of TRIGGER SOURCE switch), the ac line frequency (LINE position), or an external sync signal (EXT position).
- 3-8. When the TRIGGER LEVEL control is in AUTO position, a sweep appears on the crt without application of any type of synchronizing signal; however, when a synchronizing signal above approximately 50 cps is applied, the sweep automatically synchronizes with this signal and the sweep is triggered at the point where the signal crosses the zero axis (average dc level of synchronization signal). If a synchronizing signal below approximately 50 cps is being used, the TRIGGER LEVEL control should be out of AUTO position.
- 3-9. Rotating the TRIGGER LEVEL control in a clockwise direction permits the trigger point to be set between ± 2 cm along the positive or negative-going portion of a vertical input signal, depending on whether the TRIGGER SOURCE switch is in INT+ or INT- position, respectively. When the TRIGGER SOURCE switch is in EXT position, rotating the TRIGGER LEVEL control in a clockwise direction permits the trigger point to be set between ± 7 volts along the negative-going portion of the synchronizing signal.
- 3-10. The particular type of synchronization best suited depends on the type of measurement being made and the type of crt display desired.
- 3-11. AC/DC COUPLING. Ac coupling (AC-DC switch in AC position) removes any dc level present in the vertical or horizontal input signals. This prevents excessive dc levels from deflecting the crt trace off the face of the crt, often to the point where the POSITION controls cannot bring the crt trace within view.

CAUTION


When using ac coupling, do not exceed a dc level input of 600 volts.

- 3-12. When pulse or square waves having a frequency less than 200 cps are being measured, dc coupling is recommended (AC-DC switch in DC position).
- 3-13. BEAM FINDER OPERATION. The crt trace may frequently be deflected off the crt face by excessive dc input levels or by misadjustment of the vertical POSITION and horizontal POSITION controls. The BEAM FINDER pushbutton is extremely useful under these conditions. When the BEAM FINDER is depressed, the beam is confined to the face of the crt, brightened, and defocused to prevent burning of the crt phosphor. If the crt trace is centered with the POSITION controls when the BEAM FINDER is depressed, the trace will remain on the crt face when the BEAM FINDER is released.
- 3-14. VERTICAL SENSITIVITY SELECTION. When the vertical VERNIER control is in CAL position, the VERTICAL SENSITIVITY switch provides attenuation of the vertical input signal in four calibrated steps, 10 mv/cm, 100 mv/cm, 1 v/cm, and 10 v/cm. Rotating the vertical VERNIER control in a counterclockwise direction permits continuous adjustment of sensitivity between steps, and extends 10 v/cm step to at least 100 v/cm. When the VERTICAL SENSITIVITY switch is in CAL position, a calibrating signal is automatically connected to the vertical amplifier.
- 3-15. COMMON-MODE REJECTION. Balanced input to the vertical amplifier is obtained by removing the ground jumper across two of the vertical input terminals and applying a balanced signal input. Balanced input is useful in applications where it is deasired to simultaneously amplify the out-of-phase (differential) signal and attenuate the in-phase (common mode) signals, such as hum, noise, etc.
- 3-16. A change in the relative position of the Model 120B Oscilloscope with respect to the earth's magnetic field could result in the trace becoming misaligned. To re-align the trace with the graticule, adjust SCALE, screwdriver adjustment, on the front panel (Figure 3-1).

Notes


Figures 3-2 through 3-5 assume that the FOCUS, POSITION, and INTENSITY controls are preset by the operator for the desired display.

If in doubt as to the exact function of a switch listed in figures 3-2 through 3-5, refer to figure 3-1 for a functional description.



- 1. FOCUS: Controls crt focus.
- Horizontal VERNIER: Adjusts sensitivity between ranges; in CAL position, deflection as indicated by selected VOLTS/CM position of HORIZONTAL DISPLAY switch.
- HORIZONTAL DISPLAY: 15 positions select sweep speed, 3 positions select horizontal deflection sensitivity.
- 4. TRIGGER LEVEL: Determines level of trigger point on sync signal.
- 5. TRIGGER SOURCE: Four positions select sweep synchronization.
- 6. Vertical VERNIER: Adjusts sensitivity between ranges; in CAL position, deflection as selected by VERTICAL SENSITIVITY switch.
- 7. VERTICAL SENSITIVITY: Four positions select deflection sensitivity. CAL position displays internal calibrator signal.
- 8. CAL: Adjusts calibration of vertical input.
- 9. Vertical input terminals.
- Vertical AC-DC: AC position input capacitively coupled into vertical amplifier. DC position input directly coupled into vertical amplifier.

- Vertical POSITION: Controls vertical position of crt display.
- BAL: Adjust for no vertical shift with rotation of vertical VERNIER.
- 13. SWEEP MAGNIFIER: In X1 position sweep time selected by HORIZONTAL DISPLAY. In X5 position sweep speed is 5 times faster.
- 14. EXT. SYNC OR HORIZ: External sync or horizontal amplifier input.
- 15. Horizontal AC-DC: AC position input capacitively coupled into horizontal amplifier. DC position input directly coupled into horizontal amplifier.
- 16. Z AXIS: Input for crt intensity modulation signal.
- Horizontal POSITION: Controls horizontal position of crt display.
- 18. BEAM FINDER: Returns beam to crt face regardless of horizontal and vertical POSITION settings.
- 19. INTENSITY & POWER: Applies ac line power and controls crt intensity.
- 20. SCALE: Aligns trace with graticule.




INTERNAL HORIZONTAL SWEEP:

- 1. Set vertical AC-DC to desired type of input coupling.
- Set VERTICAL SENSITIVITY to desired vertical sensitivity.
- Set vertical VERNIER to CAL for calibrated sensitivity.
- 4. Set HORIZONTAL DISPLAY to desired horizontal sweep time. Set VERNIER to CAL for calibrated sweep time.
- 5. Set SWEEP MAGNIFIER to X1 or X5, as desired.
- 6. Set TRIGGER SOURCE to desired type of horizontal sweep synchronization. If external sync is selected, connect sync signal to EXT. SYNC.
- 7. Apply vertical input signal to vertical input terminals.
- Adjust TRIGGER LEVEL for desired synchronization.

SINGLE SWEEP (OPTION 10):

- A. Set SWEEP switch to normal (N), TRIGGER SOURCE switch to EXT, and remove any external trigger source.
- B. Adjust TRIGGER LEVEL control fully clockwise.

 Minimum trigger sensitivity is obtained with the control in this position.
- C. To increase trigger sensitivity, rotate TRIGGER LEVEL control counterclockwise. Maximum sensitivity will be obtained just prior to the point where the oscilloscope sweeps intermittently.
- D. Set SWEEP switch to single (S). The instrument is now in the "armed" state and will sweep once when triggered.
- E. To rearm the sweep circuit, set SWEEP switch from Sto N and then back to S. External triggering should not be applied during this operation to prevent the single sweep from occurring immediately when the switch is returned to the S position.




- Set vertical AC-DC to desired type of input coupling.
- 2. Set VERTICAL SENSITIVITY to desired vertical sensitivity.
- 3. Set vertical VERNIER to CALfor calibrated sensitivity.
- Set HORIZONTAL DISPLAY to desired VOLTS/CM. Set VERNIER to CAL for calibrated sensitivity.
- 5. Set horizontal AC-DC to desired type of coupling.

- Apply external horizontal sweep to horizontal input terminals.
- Apply vertical input signal to vertical input terminals.

Note

Relative phase shift of horizontal and vertical amplifiers is the same $\pm 2^{\circ}$ to 100 kc only when both VERNIER controls are set to CAL.

Figure 3-3. Operation Using External Horizontal Input



- 1. Set vertical AC-DC to desired type of input coupling.
- 2. Set VERTICAL SENSITIVITY to 10 MILLI-VOLTS/CM. (Input not balanced in any other position of VERTICAL SENSITIVITY switch.)
- 3. Set vertical VERNIER to CAL for calibrated sensitivity.
- Set HORIZONTAL DISPLAY to desired horizontal sweep speed.
- Set SWEEP MAGNIFIER to X1 or X5, as desired.
- 6. Set TRIGGER SOURCE to desired type of horizontal sweep synchronization.


- 7. Remove grounding strap from vertical input terminals.
- 8. Connect vertical signal to vertical input terminals; if ac coupling is desired, connect 0.1-uf 600-volt capacitor in series with center vertical input terminal.

Note

The common-mode input signal voltage, either positive or negative, must not exceed 3 volts minus the peak amplitude of the differential input signal.

Adjust TRIGGER LEVEL for desired synchronization.

Figure 3-4. Operation Using Balanced Vertical Input



CALIBRATION ADJUSTMENTS:

- 1. Set vertical VERNIER to CAL.
- 2. Set VERTICAL SENSITIVITY to CAL.
- 3. Adjust CAL for exactly 6 cm of vertical deflection.

BALANCE ADJUSTMENTS:

- 4. Set VERTICAL SENSITIVITY to 10 MILLI-VOLTS/CM.
- 5. Set vertical AC-DC to DC.
- 6. Short vertical input terminals.
- 7. While rotating vertical VERNIER back and forth, adjust BAL for no shift of spot.

SECTION IV PRINCIPLES OF OPERATION

4-1. OVERALL BLOCK-DIAGRAM DESCRIPTION.

- 4-2. The oscilloscope is comprised of five major functional circuit groups: the vertical amplifier, the sweep generator, the horizontal amplifier, the low-voltage power supply, and the high-voltage power supply (see figure 4-1).
- 4-3. The vertical input signal is applied to the vertical amplifier through a frequency-compensated attenuator. The vertical amplifier converts the vertical input to two 180-degree-out-of-phase signals and applies the amplified signals to the crt as the vertical deflection; in addition, the vertical amplifier applies the signals to the TRIGGER SOURCE switch, when they are used as the INT+ and INT- sync signals.
- 4-4. The horizontal or sync input signal is applied to the HORIZONTAL DISPLAY switch. Depending on the setting of this switch, the signal is applied to either the TRIGGER SOURCE switch (to be used as the external sync signal) or to the horizontal amplifier (to be used as the external horizontal input signal).
- 4-5. In addition to the internal and external sync signals, the TRIGGER SOURCE switch receives 6.3 volts ac from the low-voltage power supply; this provides for a sync-signal repetition rate equal to the line-voltage frequency.

- 4-6. The sync signal selected by the TRIGGER SOURCE switch is applied to the sweep generator, wherein the sync signal initiates the horizontal sweep signal and the unblanking gate. The sweep generator applies the sweep signal to the horizontal amplifier, and the resultant amplified sweep is applied to the crt as the horizontal deflection signal. The unblanking gate is applied to the high-voltage power supply. If an external horizontal sweep is being applied in place of the sweep from the sweep generator, the external sweep is amplified by the horizontal amplifier and applied to the crt.
- 4-7. The low-voltage power supply receives 115/230-volts, single-phase power from the line and generates the following output voltages: 6.3 volts ac, a regulated +19 volts dc, +99 volts dc, +100 volts dc, -150 volts dc, +300 volts dc, and an unregulated +420 volts dc. These voltages are distributed, as required, to the high-voltage power supply, the vertical amplifier, the horizontal amplifier, and the sweep generator.
- 4-8. The high-voltage power supply generates the high voltages for the crt. The unblanking gate and Z-axis signals applied to the high-voltage power supply effectively alter the value of the power-supply voltages to allow unblanking and modulation of the crt intensity.




Figure 4-1. Overall Block Diagram

4-9. CIRCUIT ANALYSIS.

4-10. VERTICAL AMPLIFIER.

4-11. For ac coupling, capacitor C1 is placed in series with the signal path by means of the AC-DC switch. (See figure 5-6.) The input signal is then applied to VERTICAL SENSITIVITY switch S2. When the switch is in the CAL position, the input of the amplifier is directly connected to the output of the calibrator (V4, V5, and associated circuit parts). When the VERTICAL SENSITIVITY switch is in other positions, precision frequency-adjusted attenuators are inserted. These attenuators give a ten-to-one attenuation between adjacent positions. The input signal is then applied to the control grid of amplifier V1A.

4-12. Balanced input to differential amplifier V1B is obtained by removing the ground jumper across resistor R1 (ground strap on front panel) and applying a balanced signal input. Balanced input is useful in applications where it is desired to simultaneously amplify the out-of-phase (differential) signal and attenuate the in-phase (common mode) signals, such as hum, noise, etc. This rejection is an inherent property of differential amplifiers. The common-mode signals are attenuated by 40 db (100:1), whereas any differential input is amplified.

4-13. The vertical amplifier consists of three sets of balanced differential amplifiers (V1, V2, and V3) in cascade. The three stages are neutralized by plate-to-grid cross neutralization. The first stage, V1, has balance and gain adjustments. The balance adjustment (BAL) is potentiometer R16 in the cathode circuit, which adjusts the current distribution be-

tween the two triodes. Potentiometers R21 (VERNIER control) and R20 (CAL) adjust the resistance between the plates and therefore determine the gain of the amplifier. The VERTICAL VERNIER control provides a ten-to-one variation in gain between ranges of the VERTICAL SENSITIVITY switch. The second differential amplifier, V2, has potentiometer R32 (vertical POSITION control) between its cathodes. This potentiometer controls the current distribution between the two triodes and thus determines the vertical position of the crt display. The third differential amplifier, V3, is the output stage. Synchronization signals are taken from the plates of V3 for application to the TRIGGER SOURCE switch. Since the horizontal sweep circuits trigger only on the negative slope of the signal, provision is made to take the proper synchronizing signal from either plate of V3.

4-14. One section of the BEAM FINDER switch is in the cathode circuit of V3. When pressed, the switch increases the common cathode resistance and so reduces the gain of the stage that no amount of unbalance ahead of V3 can deflect the sweep off the crt.

4-15. The calibrator circuit consists of neon lamps V4, V5, and associated circuit parts. When VERT-ICAL SENSITIVITY switch S2 is placed in the CAL position, V4 ionizes and capacitor C14 begins charging. As the voltage across capacitor C14 rises, the voltage at the junction of V4 and R52 rises proportionally. When the voltage at this junction reaches the firing potential of V5, V5 ionizes. Since the conducting potential of V5 is less the firing potential, the voltage at the junction of V4 and V5 drops, and V4 deionizes. C14 discharges through R53, and the potential across V4 increases. When the potential across




Figure 4-2. Sweep Generator, Block Diagram




Figure 4-3. Sweep Generator Waveforms

V4 reaches the firing potential, V4 fires and the voltage at the junction of V4 and V5 drops, deionizing V5. C14 starts charging again, and the cycle repeats. A 60-mv square wave is developed across R54, and this signal is applied through the SENSITIVITY switch to the vertical amplifier.

4-16. SWEEP GENERATOR.

4-17. BLOCK-DIAGRAM DESCRIPTION. (See figure 4-2.) The sync signal from the TRIGGER SOURCE switch is applied to trigger generator V201. The trigger generator produces a rectangular wave with a repetition frequency equal to that of the input sync signal. This rectangular wave is applied to a differentiating network which converts it to positive and negative spikes that are coincident with the leading and trailing edges of the rectangular wave. These spikes are then applied to the input of start-stoptrigger V202.

4-18. The negative spike switches the start-stop trigger, which produces two step outputs. The positive-going output is applied through V204 to the high-voltage power supply as the crt unblanking gate, and

the negative-going output is applied to switch diode $\ensuremath{\text{CR201}}$.

4-19. Switch diode CR201 normally clamps the input to sawtooth integrator V205A to a low negative voltage, preventing sawtooth integrator V205A from generating a sawtooth waveform. When the negative-going step signal from the start-stop trigger is applied to the switch diode, however, the diode is reverse biased and allows the sawtooth integrator to generate a sawtooth waveform.

4-20. The sawtooth output of V205B is simultaneously applied to the horizontal amplifier to serve as the horizontal sweep signal and the hold-off cathode follower V203B. The output of the hold-off cathode follower is applied to the input of the start-stop trigger to terminate the sweep. The values of R and C selected by the HORIZONTAL DISPLAY switch determines the slope of the sweep and therefore the time of the sweep. Clamp V204 ensures that the sawtooth always starts at the same level. Figure 4-3 shows the relative timing of the sweep generator waveforms.

4-21. TRIGGER GENERATOR V201. (See figure 5-8.) The sync signal selected by the TRIGGER SOURCE switch is applied through capacitor C202 and resistor R201 to the input control grid of V201, which is a Schmitt trigger circuit when the TRIGGER LEVEL control is not in AUTO. The Schmitt trigger is a form of bi-stable multivibrator, and is used to obtain pulses with rapid rise and fall times.

4-22. Figure 4-4 illustrates a simplified Schmitt trigger and typical input and output waveforms. If initially the input voltage (figure 4-4) is such that V1 is




Figure 4-4. Typical Schmitt Trigger

cutoff, V2 conducts. As the input voltage becomes more positive, it eventually reaches a predetermined level (a) at which the circuit changes state; that is, V1 conducts and V2 is cutoff. If the input voltage then goes negative, the common cathode potential decreases and the grid of V2 becomes positive. When the input reaches a second predetermined level (b), V2 conducts and the circuit switches back to its initial state. The output of the circuit is a voltage step, either positive or negative depending upon the slope of the input signal.

- 4-23. The input voltage levels at which a Schmitt trigger circuit switches are called the hysteresis limits. Note that the circuit (figure 4-4) does not switch unless the input crosses both limits.
- 4-24. Trigger generator V201 has some additional features: the TRIGGER LEVEL control adjusts the bias on V201A and thus determines the level which the input trigger must reach to change state; in addition, when the TRIGGER LEVEL control is at its extreme limit, switch S202 is placed in AUTO. This opens the shunt across resistor R207 and capacitors C205 and C206, and the trigger generator becomes an astable multivibrator. This provides triggers to the stop-start trigger even though no sync is applied to the trigger generator. When a sync signal above approximately 50 cps is applied, however, the trigger generator then synchronizes with the sync signal. The step output of the trigger generator is taken from the plate of V201B and applied to a differentiating network.
- 4-25. DIFFERENTIATING NETWORK. (See figure 5-8.) The differentiating network is composed of the series combination of capacitor C207, inductor L201, and resistor R210. The r-c time constant of this network is extremely small compared with the width of the trigger generator output pulses; consequently, the signal developed across inductor L201 and resistor R210 consists of short negative and positive spikes that are coincident with the leading and trailing edges of the trigger generator output pulses. These spikes are coupled through capacitor C208 to the control grid of V202A, one half of the start-stop trigger.
- 4-26. START-STOP TRIGGER V202, CLAMP V203A. AND SWITCH DIODE CR201. (See figure 5-8.) The start-stop trigger is a Schmitt trigger circuit. A typical Schmitt trigger is described in paragraph 4-22. V202 is triggered by a negative spike pulse from the differentiating network. One output step waveform is taken from the plate of V202B and simultaneously applies to switch diode CR201 and the grid of clamp V203A. The waveform applied to V203A cuts off V203A, and thus disables the clamping action of this tube. The waveform applied to switch diode CR201 reverse-biases the diode, and thus it ceases conduction. Another step output is taken from the plate of V202A and applied through cathode follower V204 to the high-voltage power supply; this serves as the crt unblanking gate.
- 4-27. SAWTOOTH GENERATOR V205A AND SAWTOOTH CATHODE FOLLOWER V205B. (See figure

- 5-8.) Sawtooth generator V205A is a Miller integrator which produces a linear sawtooth waveform. When switch diode CR201 ceases conduction, the integrating capacitor charges through the integrating resistance, producing a negative-going potential at the control-grid of V205A. The amplified signal at the plate of V205A is coupled back through sawtooth cathode follower V205B to the integrating capacitor, completing the negative feedback required by this Miller type integrator.
- 4-28. The sawtooth signal at the cathode of V205B is also applied to SWEEP MAGNIFIER switch S102. When S102 is in the X5 position, the sawtooth applied to the horizontal amplifier has a peak amplitude five times greater than that applied when S102 is in the X1 position; hence, the angle of slope is increased five times and the sweep time is one-fifth of that selected by the HORIZONTAL DISPLAY switch.
- 4-29. The sawtooth signal at the cathode of V203B is applied to the control grid of V202A. When the slope of the signal reaches the upper hysteresis limit of the start-stop trigger, the trigger changes state; hence, the unblanking gate output of V203A is terminated. The switch diode CR201 and clamp V204 again conduct, respectively, halting the charging of the integrating capacitor and terminating the sawtooth waveform. The hold-off capacitor in the cathode of V203B charges during the rising slope of the signal output of the holdoff cathode follower but does not immediately discharge when the sawtooth input to the hold-off cathode follower terminates. This prevents the start-stop trigger from again being triggered by a negative spike until the sweep circuits have fully recovered. A different value of hold-off capacity is selected for each setting of the HORIZONTAL DISPLAY switch.

4-30. HORIZONTAL AMPLIFIER.

- 4-31. The grid of V101A (figure 5-7) receives either the sweep output from the horizontal sweep circuits or from an external sweep source, depending on the setting of the HORIZONTAL DISPLAY switch. When external sweep is being used (EXT SENSITIVITY positions), any one of three horizontal sweep sensitivities can be selected: .1 VOLTS/CM, 1 VOLTS/CM, or 10 VOLTS/CM. The AC-DC switch allows selection of direct coupling, or ac coupling through capacitor C101.
- 4-32. The horizontal amplifier consists of two differential amplifiers (V101 and V102) in cascade. When the HORIZONTAL DISPLAY switch is set to one of the EXT SENSITIVITY positions, the resistance between the cathodes of amplifier V101 consists of the horizontal VERNIER control (R275B) in series with the horizontal gain control (R104); otherwise, resistor R107 is between the cathodes. The horizontal POSITION control (potentiometer R109) between the plates of V101 controls the horizontal position of the crt trace. The second stage (V102) is neutralized by plate-to-grid cross neutralization. The output of the horizontal amplifier is taken from the plates of V102 and applied directly to the horizontal deflection plates of the crt.




Figure 4-5. Low-Voltage Power Supply, Block Diagram

4-33. One section of the BEAM FINDER switch is in the cathode circuit of V102. When pressed, the switch increases the common cathode resistance and so reduces the gain of the stage that no amount of unbalance ahead of V102 can deflect the sweep off the crt.

4-34. LOW-VOLTAGE POWER SUPPLY.

4-35. BLOCK-DIAGRAM DESCRIPTION. (See figure 4-5.) The 115/230-volt, single-phase power is applied through switch S301 to transformer T302. The transformer applies 6.3 volts ac to the vertical amplifier, horizontal amplifier, sweep generator, and high-voltage power supply for use as filament voltage; the transformer also applies appropriate ac voltages to the following: the +19-volt d-c regulated power supply; the +300-, +100-, and +99-volt dc regulated power supply; and the -150-volt dc regulated power supply.

4-36. The regulated power supplies deliver their dc outputs to the following circuits: +19 volts dc is applied to the horizontal and vertical amplifiers; and +19, +100, +300, and -150 volts dc are applied to the vertical amplifier, the horizontal amplifier, the horizontal sweep circuits, and the high-voltage power supply; in addition, the -150-volt supply applies a negative voltage to the +19-, +99-, +100-, and +300-volt supplies for use as a control voltage.

4-37. -150-VOLT DC REGULATED POWER SUP-PLY. The -150-volt supply (figure 5-9) in the 120B is used as a reference supply for the +300-, +100-, and +99-volt supplies; therefore, any change in the -150 volt supply is reflected as a change in these supply voltages. The ac voltage from T302 is rectified and partially filtered by rectifier CR303 and capaci-

tor C325A. The resulting dc voltage is regulated further by tubes V309, V310, and V311.

4-38. The circuit functions as follows: when power is applied (assuming the -150-volt supply has been adjusted properly) the cathode of V310 becomes fixed at -65 volts and the grid assumes a slightly more negative value. If a line voltage surge or load current change were to occur, tending to lower the supply voltage, V310 grid potential would tend to change by half the amount, since the grid is tied to a voltage divider between -150 volts and ground. The result is increased bias for V310, lowering its current, raising its plate voltage, which, in turn, lowers the bias on V309. This bias change in V309 lowers its resistance, decreasing the voltage drop across this element which tends to return the supply voltage to its original value.

4-39. +300-, +100- AND +99-VOLT DC REGULATED POWER SUPPLY. The +300-volt supply (figure 5-9) operates in almost exactly the same manner as the -150-volt supply except that it uses the -150-volt supply as its voltage reference. In this supply, CR301, CR302, V307, and V308 are the rectifier, series regulator, and amplifier, respectively. The +100- and +99-volt supply is further regulated by V308B, referenced to the +300-volt supply.

4-40. +19-VOLTDC REGULATED POWER SUPPLY. (See figure 5-9.) The +19-volt supply (for the filaments of vertical amplifiers V1 and V2) uses rectifier CR304 and capacitor C328 for rectifier and filter. Transistor Q301 is a series regulator using the potential across Zener diode CR302 for its voltage reference. The current in transistor Q301 determines the value of the dc voltage across the filaments.




Figure 4-6. High-Voltage Power Supply, Block Diagram

4-41. HIGH-VOLTAGE POWER SUPPLY.

4-42. BLOCK-DIAGRAM DESCRIPTION. (See figure 4-6.) Oscillator V302 generates an ac voltage and applies it to step-up transformer T301. The steppedup ac voltage is applied to rectifiers V303 and V304. The negative high-voltage output of V303 is applied to the cathode of the crt, and the negative high-voltage output of V304 is applied to the control grid of the crt. The difference between the two voltages is the crt bias and thus controls the crt intensity.

4-43. When the INTENSITY control setting is changed, a change occurs in the cathode high voltage, causing a change in the voltage level at the wiper of the -2500-volt adjust potentiometer. This results in regulator V301 altering the control voltage in a direction necessary to return the cathode high voltage to its original value; however, this now results in the control-grid high voltage being higher or lower than previously and thus the crt intensity is altered.

4-44. HIGH-VOLTAGE RECTIFIER V303. (See figure 5-10.) The ac high voltage present in one secondary winding of T301 is rectified by V303 and filtered by capacitor C308. A portion of the +100 volts dc taken from the wiper of INTENSITY potentiometer R321 is effectively in series with and opposing the high-voltage output of V303. When the BEAM FINDER pushbutton is depressed, the opposing voltage from the wiper of potentiometer R321 is effectively removed and the intensity of the crt trace is increased.

4-45. When a signal is applied to the Z AXIS input, the signal is applied through capacitor C307 to the cathode of the crt and thus modulates the crt intensity.

4-46. A voltage-divider network, consisting of resistors R313, R311, R310, R309, R307, potentiometers R312 (FOCUS control) and R308 (-2500 adjust), is tied between +300 volts dc and the cathode of the crt. The voltage present at the wiper of R312 is applied to the crt focusing grid as focusing voltage, and the voltage present at the wiper of R308 is applied to amplifier V301B as the high-voltage control voltage.

4-47. AMPLIFIER V301. (See figure 5-10.) When a change in the value of the high voltage occurs, a corresponding change occurs at the wiper of potentiometer R308. This alters the bias at the grid of V301B, and the resultant change in the plate voltage is dc coupled through R305 to the control grid of V301A. This, in turn, results in a change in the plate voltage of V301A, which is connected to the screen grid of oscillator V302. The overall effect is that when the high voltage decreases, the screen grid voltage of V302 increases to a point where the increased ac output of V302 restores the high voltage to its original value.

4-48. HIGH-VOLTAGE RECTIFIER V304. (See figure 5-10.) The ac high voltage across the other secondary of transformer T301 is rectified by V304 and filtered by capacitor C310. The negative side of the high voltage is applied through resistor R327 to the control grid of the crt. The positive side of the high voltage is applied through resistor R326 to the horizontal sweep circuits, wherein the unblanking gate is generated. When the positive-going unblanking gate is generated, the crt control grid bias becomes less negative and the crt is unblanked.

SECTION V MAINTENANCE

5-1. INTRODUCTION.

5-2. This section provides maintenance and service instructions for the Model 120B Oscilloscope. Included are troubleshooting, repair, adjustment, performance checks, and diagrams.

5-3. TEST EQUIPMENT.

5-4. Table 5-1 lists the test equipment required to maintain the Model 120B. Equipment with similar characteristics can be substituted.

5-5. TROUBLESHOOTING.

5-6. The troubleshooting procedures are divided into two categories: system troubleshooting, which is used

to isolate a malfunction to a particular functional section of the Model 120B; and sectional troubleshooting, which is used to locate the faulty detail part. Figures 5-1 through 5-4 show the location of parts whose designations are not directly imprinted on a circuit board or chassis.

5-7. SYSTEM TROUBLESHOOTING.

5-8. Most troubles occurring in the Model 120B will directly affect the display on the crt; consequently, the system-troubleshooting procedures are based on the most common types of faults detectable by crt observations. Table 5-2 lists the common types of defects that occur in oscilloscope displays, together with the circuits most likely to be at fault. After finding the faulty section, refer to the sectional troubleshooting procedures.

Table 5-1. Recommended Test Equipment

Item No.	Туре	Characteristics	Use	Model No.
1	Test Oscilloscope	Bandwidth: dc to at least 600 kc. Sensitivity: 10 mv/cm to 100 v/cm.	Observation of waveforms.	Hewlett-Packard 140A.
2	Precision DC Voltmeter	Voltage range: 10-300 volts. Accuracy: ±1%. Input impedance: 1 megohm.	Voltage measurements.	Hewlett-Packard Model 412A.
3	High-Voltage DC Voltmeter	Voltage range: 3000 volts. Accuracy: 8%. Input impedance: 100 meg- ohms.	Voltage measurements.	Hewlett-Packard Model 410C with Model 11045A Voltage Divider Probe
4	Audio Oscillator	Frequency range: 50 cps to 450 kc.	Source of sine-wave signal.	Hewlett-Packard Model 200CD.
5	AC Voltmeter	Voltage range: 1 mv to 300 v. Accuracy: 3%, depending on scale used. Frequency Range: 50 cps to 450 kc.	Voltage measurements.	Hewlett-Packard Models 400D/H/L.

Table 5-1. Recommended Test Equipment (Cont'd)

Item No.	Туре	Characteristics	Use	Model No.
6	Square Wave Generator	Frequency range: 1 kc to 100 kc. Rise time: Less than 0.2 µsec. Amplitude: To 50 volts peak-to-peak.	Source of square wave.	Hewlett-Packard Model 211A.
7	Voltmeter Calibrator	Accuracy: 0.5%.	Accurate source of ac and dc voltages.	Hewlett-Packard Models 738A/B.
8	Time Mark Generator	Marker intervals: decade steps from 10 µsec to 100 msec. Accuracy: 1%.	Set sweep times.	Tektronix 180.
9	Power Auto- Transformer	Output voltage: 103-127 volts ac (for 115-volt input to 120B); 206-254 volts ac (for 230-volt input to 120B).	Vary line voltage.	General Radio Type W10HM.
10	Attenuator	Attenuation: 110 db in 1-db steps. Power capacity: 5 watts.	Attenuation	Hewlett-Packard Model 350D.

5-9. SECTIONAL TROUBLESHOOTING.

5-10. GENERAL. Prior to troubleshooting any functional section, a visual inspection should be performed. Check for open fuse, broken wires, discolored parts, leaky capacitors, etc. The best method for checking tubes is by substitution.

5-11. HORIZONTAL AND VERTICAL AMPLIFIERS. In the event of vertical or horizontal troubles such as unbalance or no deflection, check plate voltages, starting at the input stage and working toward the crt. Be sure the position controls are centered, no signals are applied, and the HORIZONTAL DISPLAY switch is set to an external horizontal input position. Make detailed voltage checks (see paragraph 5-67) in the first stage with incorrect plate voltages. In the event of frequency response troubles, check tubes first (by substitution) then frequency-compensating devices such as trimmer capacitors, neutralizing and bypass capacitors.

5-12. SWEEP GENERATOR. With the exception of trigger generator V201, the sweep generator circuits form a feedback loop; consequently, a failure in any functional stage in the loop results in abnormal waveforms appearing in all stages of the loop. For this reason, voltage readings are the best means for locating troubles in the sweep generator circuit. Voltage measurements for both the start-of-sweep and end-of-sweep circuit conditions are listed on figure 5-8. In

the event of sweep failure, it is recommended that both voltage measurements be employed to isolate the trouble. A10 to 15% deviation from the values given can be expected, a larger deviation indicates a source of trouble.

5-13. LOW-VOLTAGE POWER SUPPLY. When checking the power supplies, check the -150-volt supply first, for it affects all supplies. Check the other supplies in any order. Check all vacuum tubes and transistor Q301; if normal, make voltage checks (see paragraph 5-67). Voltage and ripple tolerances are given in table 5-4.

CAUTION

Do not operate the Model 120B with incorrect power supply voltages for prolonged periods of time. Where the procedure calls for a measurement, turn the instrument on just long enough to make the measurement; then turn the instrument off again.

5-14. HIGH-VOLTAGE POWER SUPPLY.

WARNING

Use caution when measuring high voltages. Use equipment suited for high-voltage measurements.




Figure 5-1. Top View, Location of Parts and Adjustments

5-15. Measure the voltages supplied to the crt. If they are normal, replace the crt. If the high voltages are not present, check that oscillator V302 is oscillating. Note that a fault in the crt cathode supply affects the crt grid supply, whereas a fault in the crt grid supply has no effect on the cathode supply. If both crt supplies are excessively high, or both excessively low, make voltage checks on V301 (see paragraph 5-67).

Note

Do not reset high voltage adjustment R308 unless the need for such adjustment is clearly indicated. The adjustment of high voltages affects the sensitivity of the crt and makes necessary the readjustment of vertical and horizontal gain and time scales.




Figure 5-2. High-Voltage Power Supply, Location of Parts

Table 5-2. System Troubleshooting

Symptom	Probable Trouble	Paragraph Reference
Nothing visible on crt with	1. Low-voltage power supply.	1. Paragraphs 4-34 and 5-13
BEAM FINDER pressed.	2. Vertical amplifier.	2. Paragraphs 4-10 and 5-11
	3. Horizontal amplifier.	3. Paragraphs 4-30 and 5-11
	4. High-voltage power supply.	4. Paragraphs 4-41 and 5-14
	5. Crt.	5. Paragraph 5-21
Vertical sensitivity out of specifications on all sensitivity ranges; horizontal sweep normal.	1. Vertical amplifier.	1. Paragraphs 4-10 and 5-11
Vertical sensitivity out of specifications on one range.	2. VERTICAL SENSITIVITY switch S2.	
External horizontal sensitivity out of specifications; vertical sensitivity normal.	1. Horizontal amplifier.	1. Paragraphs 4-30 and 5-11
Faulty sweep; external horizontal deflection normal.	1. Sweep generator circuits.	1. Paragraphs 4-16 and 5-12
Poor focusing; intensity	1. High-voltage power supply.	1. Paragraphs 4-41 and 5-14
normal.	2. Crt	2. Paragraph 5-21
Poor intensity.	1. Low-voltage power supply.	1. Paragraphs 4-34 and 5-13
	2. High-voltage power supply.	2. Paragraphs 4-41 and 5-14
	3. Crt	3. Paragraph 5-21




Figure 5-3. Vertical Sensitivity (A2) and Trigger Source (A201) Switches, Location of Parts and Adjustments

5-16. REPAIR.

5-17. REPLACEMENT OF SEMICONDUCTORS.

5-18. Excessive heat can destroy semiconductors. When soldering or unsoldering transistors or diodes, place a heat-sink (such as long-nose pliers) on the lead of the part; in addition, isolate the Model 120B from ground, or ground the body of the soldering iron to prevent leakage current from damaging the part.

Note

When replacing Q301, use a thin coat of silicone grease (hpStock No. 8500-0059) on each side of the insulator to improve heat transfer from transistor to deck.

5-19. SERVICING ETCHED CIRCUIT BOARDS.

5-20. Figure 5-5 illustrates the recommended method of servicing etched circuit boards. Removal of

components, such as tube sockets, that are attached to the board at more than two points is difficult when trying to remove the part intact. Simplify the removal by first cutting the pins or other connections between the body of the part and the circuit board, and then remove the pins individually.

5-21. CRT REPLACEMENT.

WARNING

When replacing the crt, handle crt with care; wear gloves and plastic face mask or goggles.

5-22. Replace the crt as follows:

- a. Remove four mounting screws from bezel, and remove bezel.
- b. Loosen clamp screw (figure 5-1) on crt base; do not remove screw or clamp.



Figure 5-4. Right-Side View, Side Panel Removed, Location of Parts and Adjustments

- c. Remove socket from crt base.
- d. Slide crt forward and out.
- e. Replace in reverse order.
- $f\,.$ Energize the Model 120B and obtain a free-running trace.
- g. If necessary, align graticule and trace by adjusting SCALE control.

5-23. ADJUSTMENTS.

5-24. ADJUSTMENTS FOLLOWING REPAIR.

5-25. Table 5-3 lists the adjustments required following the replacement of a tube, transistor, or diode. If a part associated with an item listed in the table is replaced, check the adjustment of the listed item.

5-26. The following paragraphs, 5-27 through 5-51, describe the adjustments necessary to align the Model 120B.

5-27. LOW-VOLTAGE POWER SUPPLY.

5-28. Table 5-4 lists the tolerances of the dc voltage outputs of the low-voltage power supply. If any voltage is not within tolerance it is probable that the line voltage is abnormal, a malfunction has occurred, or the replacement of a tube or part has caused the misadjustment. If it is confirmed that the power supply and line voltage are normal and the voltages are not within tolerance, adjustment is then required.

5-29. -150-VOLT ADJUSTMENT. Using a dc VTVM, adjust potentiometer R352 (figure 5-1) for -150 volts

5-30. +19-VOLT ADJUSTMENT. There is no adjustment for the +19-volt output; if out of tolerance a faulty transistor or part is indicated, or a fault exists in the -150-volt power supply.

5-31. +300-VOLT ADJUSTMENT. There is no adjustment for the +300-volt output; if out of tolerance a faulty tube or part is indicated, or a fault exists in the -150-volt power supply.

5-32. +100- AND +99-VOLT ADJUSTMENT. There is no adjustment for these outputs; if out of tolerance a faulty tube or part is indicated, or a fault exists in the -150-volt power supply.

Note

If the +300 volts dc is within tolerance and the +100 and/or +99 volts dc are not within tolerance, a fault exists in V308 or associated parts.

5-33. HIGH-VOLTAGE POWER SUPPLY.

5-34. Adjust the high-voltage power supply as follows:

Note

Adjustment of the high voltage affects crt deflection sensitivity, intensity, focus, and astigmatism. Check horizontal and vertical gain adjustments following any adjustment of the high voltage. Intensity, focus, and astigmatism adjustments are included in the following adjustment of the high voltage power supply.

WARNING

Voltages in excess of 2,500 volts are present in the high-voltage power supply. Take all possible precautions when performing high-voltage measurements.

a. Connect high-voltage voltmeter between terminal 17 or 18 of transformer T302 and ground.

b. Adjust potentiometer R308 (figure 5-1) for a voltmeter reading of -2500 volts.

SERVICING ETCHED CIRCUIT BOARDS

Excessive heat or pressure can lift the copper strip from the board. Avoid damage by using a low power soldering iron (50 watts maximum) and following these instructions. Copper that lifts off the board should be cemented in place with a quick drying acetate base cement having good electrical insulating properties.


A break in the copper should be repaired by soldering a short length of tinned copper wire across the break.

Use only high quality rosin core solder when repairing etched circuit boards. NEVER USE PASTE FLUX. After soldering, clean off any excess flux and coat the repaired area with a high quality electrical varnish or lacquer.


When replacing components with multiple mounting pins such as tube sockets, electrolytic capacitors, and potentiometers, it will be necessary to lift each pin slightly, working around the components several times until it is free.

WARNING: If the specific instructions outlined in the steps below regarding etched circuit boards without eyelets are not followed, extensive damage to the etched circuit board will result.


 Apply heat sparingly to lead of component to be replaced. If lead of component passes through an eyelet in the circuit board, apply heat on component side of board. If lead of component does not pass through an eyelet, apply heat to conductor side of board.




3. Bend clean tinned leads on new part and carefully insert through eyelets or holes in board.



Reheat solder in vacant eyelet and quickly insert a small awl to clean inside of hole. If hole does not have an eyelet, insert awl or a #57 drill from conductor side of board.




4. Hold part against board (avoid overheating) and solder leads. Apply heatto component leads on correct side of board as explained in step 1.




In the event that either the circuit board has been damaged or the conventional method is impractical, use method shown below. This is especially applicable for circuit boards without eyelets.

1. Clip lead as shown below.



2. Bend protruding leads upward. Bend lead of new component around protruding lead. Apply solder using a pair of long nose pliers as a heat sink.



This procedure is used in the field only as an alternate means of repair. It is not used within the factory.

Figure 5-5. Servicing Etched Circuit Boards

Table 5-3. Adjustments Following Tube, Transistor, and Diode Replacement

Reference Designation	Function	Adjustment and Paragraph
	Vertica	al Amplifier
V1	Amplifier	1. Balance adjustment (figure 3-5)
		2. Gain adjustment (paragraph 5-37)
		3. Neutralization adjustment (paragraphs 5-38 and 5-40)
V2	Amplifier	1. Balance adjustment (figure 3-5)
		2. Gain adjustment (paragraph 5-37)
		3. Neutralization adjustment (paragraphs 5-39 and 5-40)
V3	Amplifier	1. Balance adjustment (figure 3-5)
		2. Gain adjustment (paragraph 5-37)
		3. Neutralization adjustment (paragraph 5-39)
V4	Calibrator	None
V5	Calibrator	1. Calibrator adjustment (paragraph 5-41)
	Horizont	al Amplifier
V101	Amplifier	1. Gain adjustment (paragraph 5-43)
		2. X1 Sweep adjustment (paragraph 5-49)
		3. Neutralization adjustment (paragraph 5-44)
V102	Amplifier	1. Gain adjustment (paragraph 5-43)
		2. X1 Sweep adjustment (paragraph 5-49)
		3. Neutralization adjustment (paragraph 5-44)
	Sweep	Generator
V201	Trigger generator	Trigger sensitivity adjustment (paragraph 5-47)
V202	Start-stop trigger	Preset adjustment (paragraph 5-46)
V203	Clamp and hold-off cathode follower	None
V204	Gate-out cathode follower	None
V205	Sawtooth integrator and cathode follower	Sweep time adjustment (paragraph 5-50)
V206		Preset adjustment (paragraph 5-46)
V207		Sweep length adjustment (paragraph 5-51)
V208		None
V209		None
CR201	Switch diode	None

Table 5-3. Adjustments Following Tube, Transistor, and Diode Replacement (Cont'd)

Reference Designation	Function	Adjustment and Paragraph						
High-Voltage Power Supply								
V301 V302 V303 V304 V305	Amplifier Oscillator Rectifier Rectifier CRT	Adjust horizontal gain (paragraph 5-43) Adjust vertical gain (paragraph 5-37) Adjust sweep times (paragraph 5-48)						
	Low-Voltage Power Supply							
V307	Regulator	None						
V308	Amplifier-output cathode follower	None						
V309	Regulator	None						
V310	Amplifier	Adjust -150 volts (paragraph 5-29)						
V311	Reference tube	Adjust -150 volts (paragraph 5-29)						
Q301	Heater regulator	None						
CR301-CR304	Rectifiers	None						
CR305	Reference diode	None						

Table 5-4. Low-Voltage Power Supply Voltages

Voltage**	Tolerance*	Typical ** Ripple	Typical** Resistance			
-150 volts dc	VTVM Accuracy (±3%)	5 mv	10K			
+ 19 volts dc	-1.5 volts; +1 volt	45 mv	4K (with V101 removed)			
+300 volts dc	±9 volts	45 mv	75K			
+100 volts dc	±3 volts	15 mv	50K			
+ 99 volts dc	±3 volts	15 mv				

*Line voltage 115 or 230 volts ac, as required.

**With respect to chassis ground.

c. Switch HORIZONTAL DISPLAY to 1 VOLTS/CM and center the spot.

d. Set INTENSITY control to 9 o'clock and adjust R320 (figure 5-1) to the point where the spot just extinguishes.

e. Increase INTENSITY control and adjust FOCUS control for best spot.

f. Adjust Astigmatism control R316 (figure 5-1) for small round spot readjusting FOCUS control as required.

5-35. VERTICAL AMPLIFIER.

5-36. BALANCE ADJUSTMENT. Adjust the vertical amplifier balance as described in figure 3-5.

5-37. GAIN ADJUSTMENT. Adjust the vertical amplifier gain as follows:

a. Set VERTICAL SENSITIVITY to 10 MILLI-VOLTS/CM.

- b. Set vertical VERNIER to CAL.
- c. Using voltmeter calibrator, apply a 400-cps 0.1-volt peak-to-peak signal to the vertical input terminals.
- d. Adjust CAL screwdriver adjustment for a crt deflection of 10 cm.
- 5-38. ATTENUATOR FREQUENCY COMPENSATION AND FIRST-STAGE-NEUTRALIZATION ADJUSTMENTS. Adjust the vertical amplifier attenuator-frequency compensation and first-stage neutralization as follows:
- a. Connect square-wave generator to the vertical input terminals.
 - b. Rotate vertical VERNIER fully counterclockwise.
- c. Set VERTICAL SENSITIVITY to 100 MILLI-VOLTS/CM.
 - d. Set vertical AC-DC to AC.
 - e. Set HORIZONTAL DISPLAY to 0.5 MSEC/CM.
- f. Adjust output of generator to 1 kc and set amplitude for 10 cm of deflection on crt.
- g. Adjust capacitor C6 (figure 5-3) for best squarewave pattern on crt.
- h. Rotate vertical VERNIER to CAL.
- i. Readjust square-wave generator for 10 cm of deflection on crt.
- j. Adjust C9 (figure 5-4) for best square-wave pattern on crt.
- k. Repeat adjustment of C6 and C9 until best squarewave pattern is obtained at the extreme vernier settings.

Note

There may be a capacitor in parallel with C9 which serves to optimize the adjustment range of C9. When changing V1 it may be necessary to alter the value of the capacitor, or add it if not present.

- 1. Set VERTICAL SENSITIVITY to 1 VOLTS/CM.
- m. Readjust square-wave generator for 10 cm of deflection on crt.
- n. Adjust capacitor C4 (figure 5-3) for best squarewave pattern on crt.
- o. Set VERTICAL SENSITIVITY to 10 VOLTS/CM.
- p. Readjust square-wave generator for 10 cm of deflection on crt.
- q. Adjust capacitor C2 (figure 5-3) for best square-wave pattern on crt.
- 5-39. THIRD-STAGE VERTICAL-NEUTRALIZATION ADJUSTMENT. Adjust the third-stage vertical neutralizers as follows:
- a. Rotate vertical VERNIER fully counterclockwise.
- b. Set VERTICAL SENSITIVITY to 10 MILLI-VOLTS/CM.
 - c. Set vertical AC-DC to AC.
 - d. Set HORIZONTAL DISPLAY to 5 μ SEC/CM.
 - e. Set TRIGGER SOURCE to INT+.
 - f. Turn TRIGGER LEVEL to AUTO.
- g. Using square-wave generator, apply a 100-kc square wave to vertical input terminals.
- h. Adjust generator output to give 10-cm deflection, and center the pattern vertically.
- i. Using test oscilloscope, monitor the cathode of V3.

j. Adjust C12 and C13 (figure 5-1) simultaneously, for the best square wave on both test oscilloscope and scope under test.

Notes

Ignore the very fast overshoot at the leading edge as viewed on monitor scope.

There may be a capacitor in parallel with C13 which serves to optimize the adjustment range of C13. When changing V2 or V3 it may be necessary to alter the value of the capacitor, or add it if not present.

- 5-40. SECOND-STAGE VERTICAL NEUTRALIZATION ADJUSTMENT. Adjust the second-stage vertical neutralizers as follows:
- a. Rotate vertical VERNIER to CAL.
- b. Repeat steps b through h of paragraph 5-39.
- c. Adjust C10 and C11 (figure 5-1) simultaneously for best square wave on scope.

Note

There may be a capacitor in parallel with C10 which serves to optimize the adjustment range of C10. When changing V1 or V2 it may be necessary to alter the value of the capacitor, or to add it if not present.

- 5-41. CALIBRATOR ADJUSTMENT. Adjust the output of the calibrator as follows:
- a. Adjust vertical gain as described in paragraph 5-37.
- b. Set VERTICAL SENSITIVITY to CAL.
- c. Turn vertical VERNIER to CAL.
- d. Set HORIZONTAL DISPLAY to 1 MILLISEC-ONDS/CM.
- e. Set TRIGGER SOURCE to INT-.
- f. Turn TRIGGER LEVEL to AUTO.
- g. Adjust potentiometer R51 (figure 5-1) for a crt deflection of 6 cm .

5-42. HORIZONTAL AMPLIFIER.

- 5-43. GAIN ADJUSTMENT. Adjust horizontal gain as follows:
- a. Set HORIZONTAL DISPLAY to .1 VOLTS/CM.
- b. Turn horizontal VERNIER to CAL.
- c. Using voltmeter calibrator, apply a 400-cps 1-volt peak-to-peak signal to the horizontal input terminals.
- d. Adjust horizontal gain potentiometer R104 (figure 5-1) for a peak-to-peak crt deflection of 10 cm.
- 5-44. HORIZONTAL NEUTRALIZER ADJUSTMENT. Adjust horizontal neutralization as follows:
 - a. Set VERTICAL SENSITIVITY to 1 VOLTS/CM.
 - b. Turn vertical VERNIER to CAL.
 - c. Set HORIZONTAL DISPLAY to .1 VOLTS/CM.
 - d. Turn horizontal VERNIER to CAL.

- e. Using oscillator, apply an 8-kc sine wave to vertical input terminals and the sync input of square-wave generator.
- f. Using square-wave generator, apply a 100-kc 1-volt peak-to-peak square wave to horizontal input terminals.
- g. Adjust oscillator frequency to synchronize sine wave and square wave on crt (stabilize presentation).
- h. Adjust C103 and C104 (figure 5-1) for best square-wave response.
- 5-45. ATTENUATOR FREQUENCY-COMPENSATION ADJUSTMENT. Adjust the horizontal attenuator frequency compensation as follows:

a. Set VERTICAL SENSITIVITY to 1 VOLTS/CM.

- b. Turn vertical VERNIER to CAL.
- c. Turn horizontal VERNIER to CAL.
- d. Set HORIZONTAL DISPLAY to 1 VOLTS/CM.
- e. Using square-wave generator, apply a 1-kc 10-volt peak-to-peak square wave to the horizontal input terminals.
- f. Using oscillator, apply an 800-cps 10-volt peak-to-peak signal to the vertical input and sync input of square-wave generator.
- g. Adjust oscillator to synchronize sine wave and square wave on crt (stabilize presentation).
- h. Adjust capacitor C235 (figure 5-1) for optimum square wave on crt.
- i. Set HORIZONTAL DISPLAY to 10 VOLTS/CM.
- j. Increase square-wave generator output to 50 volts peak-to-peak.
- k. Adjust capacitor C233 (figure 5-1) for optimum square-wave on crt.
- 5-46. PRESET ADJUSTMENT. Adjust preset as follows:
 - a. Set VERTICAL SENSITIVITY to CAL.
- b. Set HORIZONTAL DISPLAY to .5 MILLISEC-ONDS/CM.
 - c. Set TRIGGER SOURCE to INT+.
 - d. Turn TRIGGER LEVEL just out of AUTO.
- e. Connect dc voltmeter (-100-volt range) between pin 2 of V202 and ground.
- f. Adjust potentiometer R258 (figure 5-1) clockwise until crt sweep free-runs, then counterclockwise until the sweep just stops; note the readings on the voltmeter.
- g. Adjust voltage to 3 volts less negative than the last reading.
- 5-47. TRIGGER-SENSITIVITY ADJUSTMENT. Adjust the trigger sensitivity as follows:
- a. Set VERTICAL SENSITIVITY to 100 MILLIVOLTS/CM.
- b. Set HORIZONTAL DISPLAY to 5 MILLISECONDS/CM.
 - c. Turn both VERNIER controls to CAL.
 - d. Set TRIGGER SOURCE to EXT.
 - e. Turn TRIGGER LEVEL to AUTO.
 - f. Set SWEEP MAGNIFIER to X5.
- g. Set vertical and horizontal AC-DC switches to AC.
- h. Connect oscillator to both the VERTICAL and HORIZONTAL inputs and set the frequency to 450 kc and amplitude to 0.16 volts rms (using hp Model 400D/H/L AC VTVM).
- i. Adjust R203 (trigger sensitivity) fully counter-clockwise.

- j. Observing crt presentation, adjust R203 clockwise until the presentation becomes stable.
- k. Adjust oscillator output amplitude down to 0.1 v rms, presentation should become slightly unstable between 0.15 and 0.10 v rms.
- 1. Set oscillator output amplitude to 0.5 v rms, and adjust frequency from 50 cps to 450 kc. Presentation should remain stable across complete frequency range.

5-48. SWEEP GENERATOR.

5-49. X1 SWEEP ADJUSTMENT. Adjust the X1 sweep as follows:

- a. Set VERTICAL SENSITIVITY to 1 VOLTS/CM.
- b. Turn vertical VERNIER to CAL.
- c. Turn horizontal VERNIER to CAL.
- d. Set HORIZONTAL DISPLAY to 5 MILLISECONDS/CM.
 - e. Set SWEEP MAGNIFIER to X1.
 - f. Set TRIGGER SOURCE to INT-.
 - g. Turn TRIGGER LEVEL to AUTO.
- h. Using time mark generator, apply 100-cps time markers to the vertical input terminals.
- i. Adjust X1 sweep gain R267 (figure 5-1) to obtain 5 cycles per 10 cm on the crt.

5-50. SWEEP-TIME ADJUSTMENT. Adjust the horizontal sweep time as follows:

- a. Set VERTICAL SENSITIVITY to 1 VOLTS/CM.
- b. Turn vertical VERNIER to CAL.
- c. Turn horizontal VERNIER to CAL.
- d. Set TRIGGER SOURCE to INT-.
- e. Set SWEEP MAGNIFIER to X1.
- f. Connect time mark generator to the vertical input terminals.
- g. Referring to table 5-5, adjust the time mark generator output and the HORIZONTAL DISPLAY switch to the indicated marker interval and sweep time, respectively, for each step; adjust or check for the indicated markers per 10 cm listed in the table.

5-51. SWEEP LENGTH ADJUSTMENT. Adjust the sweep length as follows:

- a. Set VERTICAL SENSITIVITY to 100 MILLIVOLTS/CM.
 - b. Turn vertical VERNIER to CAL.
 - c. Set vertical AC-DC to AC.
- d. Set HORIZONTAL DISPLAY to .5 MILLISEC-ONDS/CM.
 - e. Turn horizontal VERNIER to CAL.
 - f. Set SWEEP MAGNIFIER to X1.
 - g. Set TRIGGER SOURCE to INT-.
- h. Turn TRIGGER LEVEL to AUTO.
- i. Adjust potentiometer R254 (figure 5-1) for a sweep length of 10.75 cm (minimum length on any range should be 10.5 cm).

5-52. PERFORMANCE CHECK.

- 5-53. The following paragraphs, 5-54 through 5-66, list the various performance checks to determine that the Model 120B is performing properly.
- 5-54. VERTICAL ATTENUATOR-ERROR CHECK. Check the vertical attenuator error as follows:
 - a. Set vertical AC-DC to DC.
- b. Set VERTICAL SENSITIVITY to 10 MILLIVOLTS/CM.
- c. Turn vertical VERNIER to CAL.

Table 5-5. Horizontal Sweep-Time Adjustment

Step	Marker Interval		Sweep Time	Adjust	Markers per 10 cm
1	10 μsec	5	μSEC/CM	C227	5
2	10 μsec	10	μSEC/CM	C227 *	10
3	10 μsec	20	μSEC/CM	C227 *	20
4	100 μsec	50	μSEC/CM	C225	5
5	100 μsec	100	μSEC/CM	C225 *	10
6	100 μsec	200	$\mu \text{SEC/CM}$	C225 *	20
7	1 ms	. !	5 MILLISECONDS/CM	C223	5
8	1 ms	1	MILLISECONDS/CM	C223 *	10
9	1 ms	2	MILLISECONDS/CM	C233 *	20
10	10 ms	5	MILLISECONDS/CM	R267	5
11	10 ms	10	MILLISECONDS/CM	R267 *	10
12	10 ms	20	MILLISECONDS/CM	R267 *	20
13	100 ms	50	MILLISECONDS/CM	R247	5
14	100 ms	100	MILLISECONDS/CM	R247 *	10
15	100 ms	200	MILLISECONDS/CM	R247 *	20

^{*} Do not adjust if indication is within ±0.5 cm of that listed in the "markers per 10 cm" column.

- d. Using voltmeter calibrator, apply a 400-cps 0.1-volt peak-to-peak signal to the vertical input
- terminals.
 e. Adjust CAL for a crt deflection of exactly 10 cm.
- f. Set VERTICAL SENSITIVITY to 100 MILLIVOLTS/CM.
- g. Adjust voltmeter calibrator output to 1 volt peak-to-peak.
- h. Vertical deflection should be 10 ± 0.3 cm. Repeat step for 1 and 10 volts/cm positions of VERTICAL SENSITIVITY switch, adjusting voltmeter calibrator output to 10 and 100 volts peak-to-peak, respectively; vertical deflection should be 10 ± 0.3 cm in both cases.
- 5-55. VERTICAL DC SHIFT CHECK. Check the dc shift as follows:
- a. Set VERTICAL SENSITIVITY to 10 MILLI-VOLTS/CM.
- b. Set vertical AC-DC to AC.
- c. Turn vertical VERNIER to CAL.
- d. Short vertical input terminals to ground.
- e. Switch HORIZONTAL DISPLAY to 10 VOLTS/CM, and observe the spot.
- $\ensuremath{\text{f.}}$ Switch vertical AC-DC switch to DC, and observe the spot.

- g. Vertical shift should be approximately $0.2\ \text{cm}$ or less.
- 5-56. VERTICAL FREQUENCY-RESPONSE CHECK. Check vertical frequency response as follows:
- a. Set VERTICAL SENSITIVITY to 10 MILLI-VOLTS/CM.
 - b. Turn vertical VERNIER to CAL.
 - c. Set vertical AC-DC to AC.
 - d. Set TRIGGER SOURCE to INT+.
 - e. Turn TRIGGER LEVEL to AUTO.
- f. Set HORIZONTAL DISPLAY to 1 MILLISEC-ONDS/CM
- ONDS/CM.
 g. Using oscillator, apply a 4.5-kc signal to the input
- of attenuator; adjust for 10-db of attenuation.

 h. Connect the output of attenuator to the vertical
- input terminals.

 i. Set oscillator output to provide 10 cm of vertical deflection.
- j. Monitor output with ac voltmeter and note voltage reading.
- k. Maintaining voltage reading in step j, change oscillator frequency to 450 kc.
- 1. Display amplitude should be at least 7 cm peak-to-peak.

- 5-57. HORIZONTAL DC SHIFT CHECK. Check dc shift as follows:
- a. Set HORIZONTAL SENSITIVITY to .1 VOLTS/CM.
 - b. Turn horizontal VERNIER to CAL.
 - c. Short horizontal input terminals.
- d. Center spot and alternately switch horizontal AC-DC to AC and DC positions.
- e. Spot should shift less than 0.2 cm.
- 5-58. HORIZONTAL ATTENUATOR-ERROR CHECK. Check attenuator error as follows:
 - a. Set HORIZONTAL DISPLAY to .1 VOLTS/CM.
 - b. Turn horizontal VERNIER to CAL.
- c. Using voltmeter calibrator, apply a 400-cps 1-volt peak-to-peak sine wave to the horizontal input terminals.
- d. Adjust horizontal gain potentiometer R104 (figure 5-1) to give 10-cm deflection.
- e. Change HORIZONTAL DISPLAY to 1 VOLTS/CM and voltmeter calibrator output to 10 volts peak-to-peak.
 - f. Horizontal deflection should be 10 ± 0.5 cm.
- g. Change HORIZONTAL SENSITIVITY to 10 VOLTS/CM and voltmeter calibrator output to 100 volts peak-to-peak.
 - h. Horizontal deflection should be 10 ± 0.5 cm.
- 5-59. HORIZONTAL PHASE-SHIFT CHECK. Check phase shift as follows:
- a. Set VERTICAL SENSITIVITY to 100 MILLI-VOLTS/CM.
- b. Turn vertical VERNIER to CAL.
- c. Set HORIZONTAL DISPLAY to .1 VOLTS/CM.
- d. Turn horizontal VERNIER to CAL.
- e. Set vertical and horizontal AC-DC to AC.
- f. Using oscillator, apply a 100-kc 0.5-volt peak-to-peak sine wave to both vertical and horizontal input terminals.
- g. Pattern opening on crt should be less than 0.2 cm (±2 degrees).
- h. Change VERTICAL SENSITIVITY to 1 VOLTS/CM, HORIZONTAL DISPLAY to 1 VOLTS/CM, and voltmeter calibrator output to 5 volts peak-to-peak.
- i. Indication should be same as step g.
- j. Change VERTICAL SENSITIVITY to 10 VOLTS/CM, HORIZONTAL DISPLAY to 10 VOLTS/CM, and voltmeter calibrator output to 50 volts peak-to-peak.
- k. Indication should be same as step g.
- 5-60. HORIZONTAL RESPONSE CHECK. Checkfrequency response as follows:
 - a. Set HORIZONTAL DISPLAY to 1 VOLTS/CM.
- b. Turn horizontal VERNIER to CAL.
- c. Using oscillator, apply a 4.5-kc signal to the horizontal input terminals.
- d. Set oscillator output to provide a 10-cm trace.
- $\boldsymbol{e}.$ Monitor output with ac voltmeter and note voltage reading.
- f. Maintaining voltage reading in step e, change oscillator frequency to $300\ \mathrm{kc}$.
- g. Trace length should be greater than 7 cm (3-db point).
- 5-61. EXTERNAL TRIGGER-SENSITIVITY CHECK. Check external trigger sensitivity as follows:
- a. Set VERTICAL SENSITIVITY to 1 VOLTS/CM.

- b. Set vertical AC-DC to AC.
- c. Turn vertical VERNIER to CAL.
- d. Set HORIZONTAL DISPLAY to 5 μ SEC/CM.
- e. Set TRIGGER SOURCE to EXT.
- f. Set TRIGGER LEVEL to AUTO.
- g. Using oscillator, apply a sine wave to both the vertical and horizontal input terminals.
- h. Vary oscillator frequency from 50 cps to 450 kc, maintaining a 0.53-volt input (1.5 volts peak-to-peak).
- i. Presentation should be stable over frequency range in step h.
- 5-62. SYNC POLARITY AND TRIGGER LEVEL-RANGE CHECK. Check sync polarity and triggerlevel range as follows:
 - a. Set VERTICAL SENSITIVITY to 10 VOLTS/CM.
 - b. Turn vertical VERNIER to CAL.
 - c. Set TRIGGER SOURCE to EXT.
- d. Apply a 7.0-volt r-m-s 400-cps signal to vertical and external sync inputs.
- e. Center pattern on crt.
- f. Rotate TRIGGER LEVEL; triggering should be possible at any point along the negative slope of the input signal.
- 5-63. SWEEP-TIME CHECK. Check the sweep times as follows:
- a. Set VERTICAL SENSITIVITY to 1 VOLT/CM.
- b. Turn vertical VERNIER to CAL.
- c. Set horizontal VERNIER to CAL.
- d. Set SWEEP MAGNIFIER to X1.
- e. Set TRIGGER SOURCE to INT-.
- f. Adjust TRIGGER LEVEL for best synchronization.
- g. Connect time mark generator to vertical input terminals.
- h. Referring to table 5-6, adjust the time mark generator output and the HORIZONTAL DISPLAY switch to the indicated markers and setting, respectively, for each step; check for the indicated markers per 10 cm listed in the table.
- 5-64. CALIBRATOR AMPLITUDE CHECK. Check the amplitude of the calibrator as follows:
 - a. Set VERTICAL SENSITIVITY to CAL.
 - b. Turn vertical VERNIER to CAL.
- c. Set HORIZONTAL DISPLAY to 1 MILLISECOND/CM.
 - d. Set TRIGGER SOURCE to INT-.
 - e. Turn TRIGGER LEVEL to AUTO.
 - f. Calibrator amplitude should be 6 ± 0.12 cm.
- 5-65. INTENSITY MODULATION CHECK. Check intensity modulation as follows:
 - a. Set VERTICAL SENSITIVITY to 10 VOLTS/CM.
 - b. Turn vertical VERNIER to CAL.
- c. Set HORIZONTAL DISPLAY to 50 $\mu \text{SECONDS}/$ CM.
- d. Using square-wave generator, apply a 50-kc 20-volt peak-to-peak square wave to the vertical input terminals.
- e. Remove shorting bar from Z axis terminal and connect clip lead from vertical input to Z axis terminal.
- f. With normal intensity, the top edge of square wave should be extinguished when 20-volt peak-topeak square wave is applied at the Z axis terminal.

Table 5-6. Horizontal Sweep Time

Step	Marker Interval		Sweep Time	Markers per 10 cm*
1	10 μsec	5	μSEC/CM	5
2	10 μsec	10	$\mu { m SEC/CM}$	10
3	10 μsec	20	$\mu \text{SEC/CM}$	20
4	100 μsec	50	$\mu \text{SEC/CM}$	5
5	100 μsec	100	$\mu \text{SEC/CM}$	10
6	100 μsec	200	$\mu \text{SEC/CM}$	20
7	1 ms		5 MILLISECONDS/CM	5
8	1 ms	1	MILLISECONDS/CM	10
9	1 ms	2	MILLISECONDS/CM	20
10	10 ms	5	MILLISECONDS/CM	5
11	10 ms	10	MILLISECONDS/CM	10
12	10 ms	20	MILLISECONDS/CM	20
13	100 ms	50	MILLISECONDS/CM	5
14	100 ms	100	MILLISECONDS/CM	10
15	100 ms	200	MILLISECONDS/CM	20

 $^{* \}pm 0.5$ cm

5-66. LINE-VOLTAGE VARIATION CHECK. Check line-voltage variation as follows:

- a. Connect power cable to power autotransformer and adjust output to 115 volts ac.
- b. Set VERTICAL SENSITIVITY to CAL.
- c. Set HORIZONTAL DISPLAY to 2 MILLISECONDS/CM.
 - d. Set TRIGGER LEVEL to AUTO.
- e. Adjust horizontal VERNIER to obtain exactly 5 cycles of calibrator signal per 10 cm; note exact amplitude of each calibrator signal.
- f. Set line voltage to 103 volts ac, then to 127 volts ac. (Allow periods of at least 2 minutes for each voltage.) Calibrator signal amplitude should be 6 ± 0.3 cm; the five cycles of the signal should change less than 0.5 cm in length.

5-67. DIAGRAMS.

5-68. Figures 5-6 through 5-11 are schematic diagrams of the Model 120B. DC voltages are provided on the schematics as an aid in troubleshooting.

5-69. The following notations are applicable to figures 5-6 through 5-11.

- a. All values are in ohms, picofarads, and microhenries unless otherwise indicated.
- b. Lettering enclosed in heavy boxes indicates frontpanel engraving.
- c. Voltage measurements are with respect to ground and made with Hewlett-Packard Model 412A VTVM.

d. Voltage measurements are made with Model 120B front-panel controls set as follows:

Control	Setting
VERTICAL SENSITIVITY switch	CAL
VERTICAL VERNIER control	CAL
Vertical AC-DC switch	AC
FOCUS control	Centered
VERTICAL POSITION control	Centered
INTENSITY control	Centered
HORIZONTAL POSITION control	Centered
HORIZONTAL DISPLAY switch	5 µSEC/CM
HORIZONTAL VERNIER control	CAL
TRIGGER SOURCE switch	INT-
TRIGGER LEVEL control	AUTO
Horizontal AC-DC switch	AC
SWEEP MAGNIFIER switch	X1




Figure 5-6. Vertical Amplifier

Table 5-6. Horizontal Sweep Time

Step	Marker Interval		Sweep Time	Markers per 10 cm*
1	10 μsec	5	μSEC/CM	5
2	10 μsec	10	$\mu { m SEC/CM}$	10
3	10 μsec	20	$\mu { m SEC/CM}$	20
4	100 μsec	50	$\mu { m SEC/CM}$	5
5	100 μsec	100	$\mu { m SEC/CM}$.	10
6	100 μsec	200	$\mu { m SEC/CM}$	20
7	1 ms	. [MILLISECONDS/CM	5
8	1 ms	1	MILLISECONDS/CM	10
9	1 ms	2	MILLISECONDS/CM	20
10	10 ms	5	MILLISECONDS/CM	5
11	10 ms	10	MILLISECONDS/CM	10
12	10 ms	20	MILLISECONDS/CM	20
13	100 ms	50	MILLISECONDS/CM	5
14	100 ms	100	MILLISECONDS/CM	10
15	100 ms	200	MILLISECONDS/CM	20

^{* ±0.5} cm

5-66. LINE-VOLTAGE VARIATION CHECK. Check line-voltage variation as follows:

- a. Connect power cable to power autotransformer and adjust output to 115 volts ac.
- b. Set VERTICAL SENSITIVITY to CAL.
- c. Set HORIZONTAL DISPLAY to 2 MILLISECONDS/
- d. Set TRIGGER LEVEL to AUTO.
- e. Adjust horizontal VERNIER to obtain exactly 5 cycles of calibrator signal per 10 cm; note exact amplitude of each calibrator signal.
- f. Set line voltage to 103 volts ac, then to 127 volts ac. (Allow periods of at least 2 minutes for each voltage.) Calibrator signal amplitude should be 6 ±0.3 cm; the five cycles of the signal should change less than 0.5 cm in length.

5-67. DIAGRAMS.

5-68. Figures 5-6 through 5-11 are schematic diagrams of the Model 120B. DC voltages are provided on the schematics as an aid in troubleshooting.

5-69. The following notations are applicable to figures 5-6 through 5-11.

- a. All values are in ohms, picofarads, and microhenries unless otherwise indicated.
- b. Lettering enclosed in heavy boxes indicates front-panel engraving.
- c. Voltage measurements are with respect to ground and made with Hewlett-Packard Model 412A VTVM.

d. Voltage measurements are made with Model 120B front-panel controls set as follows:

Control	Setting
VERTICAL SENSITIVITY switch	CAL
VERTICAL VERNIER control	CAL
Vertical AC-DC switch	AC
FOCUS control	Centered
VERTICAL POSITION control	Centered
INTENSITY control	Centered
HORIZONTAL POSITION control	Centered
HORIZONTAL DISPLAY switch	5 µSEC/CM
HORIZONTAL VERNIER control	CAL
TRIGGER SOURCE switch	INT-
TRIGGER LEVEL control	AUTO
Horizontal AC-DC switch	AC
SWEEP MAGNIFIER switch	X1




Figure 5-6. Vertical Amplifier





Figure 5-7. Horizontal Amplifier



SINGLE SWEEP OPERATION
(OPTION 10)

V203A

-150V

BLU-WHT

V10

SWEEP

N

R267

R266
SOK 47K

(SEE SWITCH DETAIL)

Sweep Completed*	Reset**
-8.15 volts -41 volts -41 volts +26.5 volts -150 volts	-1.47 volts -28 volts -1.1 volts +19.5 volts 0 volts
-55 volts +130 volts -52 volts -55 volts	-50 volts -49 volts -118 volts -3.5 volts
+26.5 volts +29 volts	+19.5 volts +22 volts
-8.5 volts +240 volts +130 volts +130 volts	-1.83 volts +48 volts -58 volts -49 volts
-25 volts	-28 volts
+73 volts	-100 volts
+185 volts	-5.1 volts
+130 volts	-58 volts
+252 volts	+95 volts
-	-58 volts
	-8.15 volts -41 volts -41 volts -41 volts +26.5 volts -150 volts -55 volts +130 volts -55 volts +26.5 volts +29 volts -8.5 volts +240 volts +130 volts +130 volts +130 volts +73 volts +185 volts +180 volts

**Reset: Connect V202 pin 2 to -150 volts

Figure 5-8. Sweep Generator




Figure 5-9. Low-Voltage Power Supply




Figure 5-10. High-Voltage Power Supply




Figure 5-11. Horizontal Display Switch

SECTION VI

6-1. INTRODUCTION.


- 6-2. This section contains information for ordering replaceable parts for the Model 120B. Table 6-1 lists reference designators and abbreviations that are used in the Table 6-2 component descriptions. Table 6-2 lists the parts in alpha-numerical order of their reference designations and provides the following information for each item:
 - a. The hp part number.
- b. Total quantity (TQ) used in the instrument; given only first time the part number is listed.
 - c. Description of part (refer to Table 6-1).
- d. Typical manufacturer of the part in a five-digit code, except for Hewlett-Packard Company; see code list of manufacturers, Table 6-3, for name.
 - e. Manufacturer's part number.
- 6-3. Parts not identified by a reference designation are listed at the end of Table 6-2, under miscellaneous. Cabinet parts and the rack mounting kit for the instrument are illustrated and listed in Figure 6-1.

6-4. ORDERING INFORMATION.

- 6-5. To order replacement parts from the Hewlett-Packard Company, address the order or inquiry to the nearest hp Sales/Service Office (see list of address at rear of this manual) and supply the following information:
 - a. The hp part number of item(s).
- b. Model number and eight-digit serial number of the instrument.
- 6--6- To order a part not listed in Table 6-2, provide the following information.
- $\boldsymbol{a}.$ Model number and eight digit serial number of the instrument.
- b. Description of part including funtion and location.
- 6-7. To order a part from a manufacturer other than the Hewlett-Packard Company, provide the complete part description and the manufacturer's part number from Table 6-2.

Table 6-1. List of Reference Designators and Abbreviations

					REFERENCE DESI	GNATORS					
A	=	assembly	E		misc electronic part	MP		mechanical part	TB	=	terminal board
В	Ξ	motor	F		fuse	P	=	plug	TP	=	test point
C		capacitor	FL		filter	Q	=	transistor	V	=	vacuum tube, neon
CP		coupling	J		jack	R		resistor			bulb, photocell, et
CR		diode	K		relay	RT		thermistor	W		cable
DL		delay line	L		inductor	S		switch	X	=	
DS	=	device signaling (lamp)	M	=	meter	T	=	transformer	Y	=	crystal
					ABBREVIATI	ONS					
Α		amperes	GE		germanium	N/C		normally closed	RMO	=	rack mount only
A.F.C		automatic frequency control	GL		glass	NE		neon	RMS	=	root-mean-square
AMPL	=	amplifier	GRD	=	ground(ed)	NIPL		nickel plate			
						N/O		normally open	S-B	=	slow-blow
		beat frequency oscillator	H		henries	NPO	=	negative positive zero	SCR	=	screw
	=		HEX		hexagonal			(zero temperature	SE		selenium
BH		binder head	HG		mercury			coefficient)	SECT	=	section(s)
BP		bandpass	HR		hour(s)	NRFR	=	not recommended for	SEMIC	CON	V = semiconductor
BRS		brass	hp	=	Hewlett-Packard			field replacement	SI	=	silicon
BWO	=	backward wave oscillator	IF		intermediate freq	NSR	=	not separately	SIL	=	silver
			IMPG		impregnated			replaceable	SL	=	slide
CCW	=	counter-clockwise	INCD	=	incandescent				SPL	=	special
CER		ceramic	INCL		include(s)	OBD		order by description	SST	=	stainless steel
CMO		cabinet mount only	INS		insulation(ed)	OH	=	oval head	SR	=,	split ring
COEF	=	coefficient	INT	=	internal	OX	=	oxide	STL	=	steel
COM		common									
	=	composition	K	=	kilo = 1000	P	=	peak	TA	=	tantalum
CONN		connector				PC	=	printed circuit	TD	=	time delay
CP		cadmium plate	LIN	=	linear taper	PF	=	picofarads =	TGL	=	toggle
CRT	=	cathode-ray tube	LK WAS		lock washer			10-12 farads	TI	=	titanium
CW	=	clockwise	LOG	=	logarithmic taper	PH BRZ	Z =	phosphor bronze	TOL	=	tolerance
			LPF	=	low pass filter	PHL	=	Phillips	TRIM	=	trimmer
DEPC	=	deposited carbon				PIV	=	peak inverse voltage	TWT	=	traveling wave tube
DR	=	drive	M		$milli = 10^{-3}$	P/O	=	part of			
			MEG	=	$meg = 10^6$	POLY	=	polystyrene	U	=	micro = 10-6
ELECT	=		METFL	M -	metal film	PORC	==	porcelain			
	=		MFR	=	manufacturer	POS	222	position(s)	VAR	=	variable
EXT	==	external	MINAT		miniature	POT		potentiometer	VDCW	=	dc working volts
			MOM	=	momentary	PP	==	peak-to-peak			
F	=	farads	MTG		mounting	PT		point	W/	=	with
FH	=	flat head	MY	=	"mylar"	RECT	=	rectifier	W	=	watts
FIL H	=	fillister head				RF	=	radio frequency	WW	=	wirewound
FXD	=	fixed	N	=	nano (10 ⁻⁹)	RH		round head	W/O	Ξ	without
01194-10)										



Index No.	hp Part No.	Description	TQ
1	120B-2D	Panel: front	1
2	120B-2C	Panel: rear	1
3	5000-0743	Cover: side	2
4	5060-0734	Casting: frame side	2
5	120B-44A-1	Cover: top	1
6	5060-0758	Cover: bottom	1
7	5060-0767	Foot: plastic	5
8	1490-0030	Stand: tilt	1
9	5060-0763	Handle: side	2
10	5060-0765	Retainer: handle	2
11	5000-0052	Plate: trim adhesive back	2
12	5060-0776	Kit: rack mount	1

Figure 6-1. Modular Cabinet Replaceable Parts

Table 6-2. Replaceable Parts

Table 6-2. Replaceable Parts								
Ref Desig	hp Part No.	RS	TQ	Description (See Table 6-1.)	Mfr	Mfr Part No.		
A1 A2 A3	120B-65F 120B-19A 120B-12E		1 1 2	A: pc vert and horiz amplifiers A: switch vertical A: ac-dc switch (incl bracket and S1)	hp hp hp			
A101 A102	120B-6C 120B-12E		1	A: vert shield (incl bracket and S102) A: ac-dc switch (incl bracket and S101)	hp hp			
A201 A202	120B-19D 120B-65G		1 1	A: switch trigger source A: pc sweep and lv supply	hp hp			
A204	120B-19B		1	A: switch horiz	hp			
A301 A302	120B-65E 120B-11B		1 1	A: pc hv supply A: rectifier (incl T301, C309, V303, V304)	hp hp			
C1 C2 C3 C4 C5	0170-0022 0130-0014 0170-0027 0130-0014 0160-2566		2 3 3	C: fxd my 0.1 uf 20% 600vdcw C: var cer 5-25 pf 500vdcw C: fxd my 0.02 uf 5% 200vdcw C: var cer 5-25 pf 500vdcw C: fxd mica 2000 pf 2% 300vdcw	84411 72982 84411 72982 hp	HEW 7 577-030-COP-39R 600UE20352 577-030-COP-39R		
C6 C7 C8 C9	0130-0014 0140-0147 0150-0012 0132-0004 0132-0004		1 9 6	C: var cer 5-25 pf 500vdcw C: fxd mica 180 pf 5% 500vdcw C: fxd cer .01 uf 20% 1000vdcw C: var poly 0.7-3 pf 350vdcw C: var poly 0.7-3 pf 350vdcw	72982 72136 71590 72982 72982	577-030-COP-39R DM15F181J 13C DISC 535-009-4R 535-009-4R		
C11 C12 C13 C14 C15	0132-0004 0132-0004 0132-0004 0150-0014 0150-0012		1	C: var poly 0.7-3 pf 350vdcw C: var poly 0.7-3 pf 350vdcw C: var poly 0.7-3 pf 350vdcw C: fxd cer 0.005 uf 500vdcw C: fxd cer .01 uf 20% 1000vdcw	72982 72982 72982 04222 71500	535-009-4R 535-009-4R 535-009-4R D1-4 13C DISC		
C16 C17 C18 C19	0170-0003 0150-0011 0150-0041 0150-0012		1 3 1	C: fxd my 0.051 uf 10% 200vdcw C: fxd ti-ox 1.5 pf 20% 500vdcw C: fxd ti-ox 2.7 pf 5% 500vdcw C: fxd cer.01 uf 20% 1000vdcw	00853 78488 78488 71590	33M02151 TYPE GA OBD TYPE GA OBD 13C DISC		
C21	0150-0031		1	C: fxd ti-ox 2 pf 5% 500vdcw	78488	TYPE GA OBD		
C101 C102 C103 C104	0170-0022 0150-0012 0132-0004 0132-0002		1	C: fxd my 0.1 µf 20% 600vdcw C: fxd cer .01 µf 20% 1000vdcw C: var poly 0.7-3 pf 350vdcw C: var poly 0.7-3 pf 350vdcw	84411 71590 72982 72982	HEW 7 13C DISC 535-009-4R 535-015-4R		
C201 C202 C203 C204 C205	0150-0011 0150-0024 0140-0201 0150-0011 0180-0050		5 1 2	C: fxd ti-ox 1.5 pf 20% 500vdcw C: fxd cer 0.02 uf -20%+80% 600vdcw C: fxd mica 12 pf 5% 500vdcw C: fxd ti-ox 1.5 pf 20% 500vdcw C: fxd elect 40 uf -15%+100% 500vdcw	78488 91418 72136 78488 56289	TYPE GA OBD BO. 02 GMV DM15C120J TYPE GA OBD D 32538		

Table 6-2. Replaceable Parts (Cont'd)

Ref	hp Part No.	RS	TQ	Description	Mfr	Mfr Part No.
Desig		1.00	14	(See Table 6-1.)	1411.1	WIII Part NO.
C206 C207 C208 C209	0180-0050 0140-0039 0140-0082 0140-0156		1 1 2	C: fxd elect 40 µf -15%+100% 500vdcw C: fxd mica 47 pf 5% 500vdcw C: fxd mica 68 pf 5% 500vdcw C: fxd mica 1500 pf 2% 300vdcw	56289 76433 76433 72136	D 32538 RCM15E47OJ RCM15E68OJ DM19F152G
C211 C212 C213 C214 C215 C216	0150-0023 0140-0041 0150-0024 0150-0012 0140-0041 0150-0012		3	C: fxd cer 2000 pf 20% 1000vdcw C: fxd mica 100 pf 5% 500vdcw C: fxd cer .02 uf -20%+80% 600vdcw C: fxd cer .01 uf 20% 1000vdcw C: fxd mica 100 pf 5% 500vdcw C: fxd cer .01 uf 20% 1000vdcw	91418 76433 91418 71590 78488 71590	JFO.002-20% RCM15E101J BO.02 GMV 13C DISC TYPE GA OBD 13C DISC
C221 C222 C223 C224 C225	0170-0028 0170-0027 0131-0003 0170-0026 0131-0004		1 1 1 1	C: fxd my 0.2 \(\text{\pm f} \) 50% 200vdcw C: fxd my 0.02 \(\text{\pm f} \) 50% 200vdcw C: var mica 170-780 pf 175vdcw C: fxd my 1800 pf 5% 200vdcw C: var mica 14-150 pf 175vdcw	84411 84411 72136 84411 72136	600UE20452 600UE20352 T52910 60QUE18252 T51410-3
C226 C227 C228 C229 C230	0140-0041 0130-0003 0160-0380 0170-0027 0160-0007		1 1	C: fxd mica 100 pf 5% 500vdcw C: var cer 1.5-7 pf NPO 500vdcw C: fxd my 0.22 \(\mu f \) 10% 200vdcw C: fxd my 0.02 \(\mu f \) 5% 200vdcw C: fxd my 2200 pf 10% 600vdcw	76433 hp hp 84411 56289	RCM15E101J 600UE20352 160P22296
C231 C232 C233 C234 C235	0140-0031 0140-0055 0130-0016 0140-0156 0130-0016		1 1 2	C: fxd mica 220 pf 10% 500vdcw C: fxd mica 150 pf 10% 500vdcw C: var cer 5-25 pf 500vdcw C: fxd mica 1500 pf 2% 300vdcw C: var cer 5-25 pf 500vdcw	76433 76433 72982 72136 72985	RCM20B221K RCM20B151K 557-019-COP-39R DM19F152G 557-019-COP-39R
C236 C237	0140-0027 0140-0035		1 1	C: fxd mica 470 pf 10% 500vdcw C: fxd mica 39 pf 5% 500vdcw	76433 76433	RCM20B471K RCM15E390J
C301 C302 C303 C304 C305	0150-0023 0140-0037 0140-0004 0150-0012 0160-0151		1 1 7	C: fxd cer 2000 pf 20% 1000vdcw C: fxd mica 390 pf 5% 500vdcw C: fxd mica 15 pf 10% 500vdcw C: fxd cer .01 \(\times \) 1000vdcw C: fxd cer .4700 pf -20% +80% 4000vdcw	91418 76433 72982 71590 71590	JFO. 002-20% RCM15E391J 535-009-4R 13C DISC DA172-097CB
C306 C307 C308 C309 C310	0150-0012 0160-0151 0160-0151 0160-0039 0160-0151		1	C: fxd cer .01 µf 20% 1000vdcw C: fxd cer 4700 pf -20%+80% 4000vdcw C: fxd cer 4700 pf -20%+80% 4000vdcw C: fxd my 0.27 µf 10% 200vdcw C: fxd cer 4700 pf -20%+80% 4000vdcw	71590 71590 71590 56289 71590	13C DISC DA172-097CB DA172-097CB 160P27492 DA172-097CB
C311 C312 C313 C314	0150-0023 0160-0151 0160-0151 0160-0151			C: fxd cer 2000 pf 20% 1000vdcw C: fxd cer 4700 pf -20%+80% 4000vdcw C: fxd cer 4700 pf -20%+80% 4000vdcw C: fxd cer 4700 pf -20%+80% 4000vdcw	91418 71590 71590 71590	JFO. 002-20% DA172-097CB DA172-097CB DA172-097CB
C321 C322A/B C323 324A B'C C325A/B	0180-0126 0180-0030 0150-0024 0180-0053 0180-0127		1 1 1	C: fxd elect 120 uf 300vdcw C: fxd elect 2 sect 120 - 40 uf 450vdcw C: fxd cer .02 uf -20%+80% 600vdcw C: fxd elect 3 sect 40-30-20 uf 150vdcw C: fxd elect 2 sect 120 - 40 uf -10%+50% 300vdcw	56289 56289 91418 56289 56289	D36236 D32352 BO. 02 GMV OBD D36235
C326 C327 C328 C329	0150-0024 0150-0012 0180-0056 0150-0024		1	C: fxd cer .02 µf -20%+80% 600vdcw C: fxd cer .01 µf 20% 1000vdcw C: fxd elect 1000 µf 50vdcw C: fxd cer .02 µf -20%+80% 600vdcw	91418 71590 56289 91418	BO. 02 GMV 13C DISC D32429 BO. 02 GMV

Table 6-2. Replaceable Parts (Cont'd)

Ref	hp Part No.	RS	TQ	Description (See Table 6.1)	Mfr	Mfr Part No.
Desig				(See Table 6-1.)		1,112 1 117 117
CR201	1901-0044		1	CR: si	hp	
CR301 CR302 CR303 CR304 CR305	1901-0030 1901-0030 1901-0030 1901-0045 1902-0225		3 1 1	CR: si CR: si CR: si CR: si CR: si CR: si	02735 02735 02735 hp	OBD OBD OBD
DS1	1450-0048		1	DS: neon indicator	08717	858-R
F301	2110-0005 2110-0020		1	F: cartridge 1.6 amp s-b (for 115 v operation) F: cartridge 0.8 amp s-b (for 230 v operation)	71400 71400	MDL1.6 OBD
J1	5060-0633 5060-0625 0340-0091 0340-0086		4 1 2 1	NSR - consists of: Binding Post: red (2 required) Binding Post: black Insulator: 3 hole Insulator: 2 hole	hp hp hp	
J101	5060-0633 5060-0626 0340-0091 0340-0087		1	NSR - consists of: Binding Post: red (2 required) Binding Post: black Insulator: 3 hole Insulator: 3 hole	hp hp hp hp	
L201 L301 L302	9140-0022 5060-0409 9140-0029		1 1 1	L: fxd rf 500 μh 10% L: coil (trace align) L: fxd rf 100 μh	99848 hp 99848	1500-15-501 3100-15-101
P301				NSR: part of power cordW1		
Q301	1850-0038		1	Q: ge pnp	hp	
R1 R2 R3 R4 R5	0686-1055 0757-0059 0757-0159 0757-0057 0757-0839		4 3 1 1	R: fxd comp 1 megohm 5% 1/2w R: fxd metflm 1 megohm 1% 1/2w R: fxd metflm 1000 ohms 1% 1/2w R: fxd metflm 990 ohms 1% 1/2w R: fxd metflm 10k ohms 1% 1/2w	01121 hp hp hp	EB1055
R6 R7 R8 R9	0757-0054 0757-0367 0686-1055 0687-4711		1 1 5	R: fxd metflm 900k ohms 1% 1/2w R: fxd metflm 100k ohms 1% 1/2w R: fxd comp 1 megohm 5% 1/2w R: fxd comp 470 ohms 10% 1/2w	hp hp 01121 01121	EB1055 EB4711
R11 R12 R13 R14 R15	0687-1041 0687-1011 0687-1011 0730-0062 0727-0197		6 12 1 2	R: fxd comp 100k ohms 10% 1/2w R: fxd comp 100 ohms 10% 1/2w R: fxd comp 100 ohms 10% 1/2w R: fxd depc 80k ohms 1% 1w R: fxd depc 59.48k ohms 1% 1/2w	01121 01121 01121 hp hp	EB1041 EB1011 EB1011

Table 6-2. Replaceable Parts (Cont'd)

R17 R18 0' R19 0' R20A/B 2': R21 2: R22 0' R23 0' R24 0' R25 0' R31 R32 2: R33 0' R32 2: R33 0' R35 0' R36 R37 R36 R37 R38 R39 R40 0' R40	2100-0054 1727-0197 1758-0030 1758-0047 2100-0174 2100-0174 2100-0174 2100-0174 2100-0174 2100-0174 2100-0174 2100-0186 2100-1486 2100-1486 2100-1486 2100-1486 2100-0186	1 2 3 1 1 1 2 1 1 3	R: var ww 500 ohms 10% 2w R: fxd depc 59.48k ohms 1% 1/2w R: fxd met ox 510 ohms 5% 1/2w R: fxd met ox 7500 ohms 5% 1/2w R: var comp log dual 100k ohms 20% 1/4w R: var comp 500k ohms 20%, 5% cw log taper,1/4w w/spdt switch R: fxd comp 100 ohms 10% 1/2w R: fxd comp 100 ohms 10% 1/2w R: fxd comp 100 ohms 5% 1/2w R: fxd met ox 510 ohms 5% 1/2w R: fxd met ox 7500 ohms 5% 1/2w R: fxd depc 68.38k ohms 1% 1w R: var comp 300 ohms 20% 3w R: fxd depc 7500 ohms 1% 1w R: fxd depc 68.38k ohms 1% 1w R: fxd depc 88.38k ohms 1% 1w	11237 hp hp 11237 01123 01121 hp hp	252 OBD OBD RGC-45 EB1011 EB1011
R22 00 R23 00 R24 0' R25 0' R31 0' R32 2: R33 0' R34 0' R35 00 R36 0 R37 00 R38 0 R39 0 R40 0'	0687-1011 0687-1011 1758-0030 0758-0047 0730-0056 100-1486 0730-0024 1730-0056 1687-2231 1687-1011 1687-1011	2 1 1	w/spdt switch R: fxd comp 100 ohms 10% 1/2w R: fxd comp 100 ohms 10% 1/2w R: fxd met ox 510 ohms 5% 1/2w R: fxd met ox 7500 ohms 5% 1/2w R: fxd depc 68.38k ohms 1% 1w R: var comp 300 ohms 20% 3w R: fxd depc 7500 ohms 1% 1w R: fxd depc 68.38k ohms 1% 1w	01121 01121 hp hp hp	EB1011
R32 2: R33 0' R34 0' R35 0' R36 0' R37 0' R38 0' R39 0' R40 0'	2100-1486 0730-0024 0730-0056 0687-2231 0687-2231 0687-1011 0687-1011	1 1	R: var comp 300 ohms 20% 3w R: fxd depc 7500 ohms 1% 1w R: fxd depc 68.38k ohms 1% 1w	hp hp hp	
R37 00 R38 00 R39 00 R40 0	0687-1011 0687-1011			01141	EB2231
R41 0	0758-0020	2 2	R: fxd comp 22k ohms 10% 1/2w R: fxd comp 100 ohms 10% 1/2w R: fxd comp 100 ohms 10% 1/2w R: fxd comp 8200 ohms 10% 1w R: fxd met ox 22k ohms 5% 1/2w	01121 01121 01121 01121 hp	EB2231 EB1011 EB1011 GB8221
R43 0	0689-1635 0687-4731 0758-0020 0690-8221	1 5	R: fxd comp 16k ohms 5% 1w R: fxd comp 47k ohms 10% 1/2w R: fxd met ox 22k ohms 5% 1/2w R: fxd comp 8200 ohms 10% 1w	01121 01121 hp 01121	GB1635 EB4731 GB8221
R52 0 R53 0	2100-0102 0727-0246 0686-1055 0727-0055	2 1 1	R: var comp 500k ohms 30% 0.1w R: fxd depc 600k ohms 1% 1/2w R: fxd comp 1 megohm 5% 1/2w R: fxd depc 201 ohms 1% 1/2w	11237 hp 01121 hp	UPE 70 SPECIAL EB1055
R102 0 R103 0 R104 2 R105 0	0687-1041 0687-1011 0687-1011 2100-0182 0690-1041 0690-1041	1 3	R: fxd comp 100k ohms 10% 1/2w R: fxd comp 100 ohms 10% 1/2w R: fxd comp 100 ohms 10% 1/2w R: var comp 3300 ohms 10% 1/3w R: fxd comp 100k ohms 10% 1w R: fxd comp 100k ohms 10% 1w	01121 01121 01121 11237 01121 01121	EB1041 EB1011 EB1011 UPE 70 GB1041 GB1041
R108 0 R109A/B 2 R110 0	0687-3321 0687-2741 2100-0258 0687-2741 0757-0059	1 3 1	R: fxd comp 3300 ohms 10% 1/2w R: fxd comp 270k ohms 10% 1/2w R: var comp dual 1 megohm 20% 1/4w R: fxd comp 270k ohms 10% 1/2w R: fxd metflm 1 megohm 1% 1/2w	01121 01121 11237 01121 hp	EB3321 EB2741 2-45 EB2741
R113 0 R114 0 R115 0	0687-1011 0757-0050 0758-0050 0687-1011 0757-0059	2	R: fxd comp 100 ohms 10% 1/2w R: fxd met ox 39k ohms 5% 1/2w R: fxd met ox 39k ohms 5% 1/2w R: fxd comp 100 ohms 10% 1/2w R: fxd metflm 1 megohm 1% 1/2w	01121 hp hp 01121 hp	EB1011

Table 6-2. Replaceable Parts (Cont'd)

Ref		T				
Desig	hp Part No.	RS	TQ	Description (See Table 6-1,)	Mfr	Mfr Part No.
R117 R118 R119 R120	0692-3635 0692-3635 0758-0047 0687-4731		2	R: fxd comp 36k ohms 5% 2w R: fxd comp 36k ohms 5% 2w R: fxd met ox 7500 ohms 5% 1/2w R: fxd comp 47k ohms 10% 1/2w	01121 01121 hp 01121	HB3635 HB3635 EB4731
R201 R202 R203 R204 R205	0687-1011 0687-1851 2100-0154 0758-0017 0758-0073		1 1 1 4	R: fxd comp 100 ohms 10% 1/2w R: fxd comp 1.8 megohms 10% 1/2w R: var comp 1000 ohms 30% 0.1w R: fxd met ox 1500 ohms 5% 1/2w R: fxd met ox 24k ohms 5% 1/2w	01121 01121 11237 hp hp	EB1011 EB1851 UPE 70
R206 R207 R208 R209 R210	0727-0202 0687-1531 0687-3921 0758-0073 0687-3921		1 2 2	R: fxd depc 83k ohms 1% 1/2w R: fxd comp 15k ohms 10% 1/2w R: fxd comp 3900 ohms 10% 1/2w R: fxd met ox 24k ohms 5% 1/2w R: fxd comp 3900 ohms 10% 1/2w	hp 01121 01121 hp 01121	EB1531 EB3921 EB3921
R211 R212 R213 R214 R215	0727-0201- 0687-1041 2100-0188 0686-1245 0686-2745		1 1 1 1	R: fxd depc 71.56k ohms 1% 1/2w R: fxd comp 100k ohms 10% 1/2w R: var comp 200k ohms 20% 1/4w R: fxd comp 120k ohms 5% 1/2w R: fxd comp 270k ohms 5% 1/2w	hp 01121 11237 01121 01121	EB1041 VF-45 EB1245 EB2745
R216	0727-0060		1	R: fxd depc 225 ohms 1% 1/2w	hp	
R221 R222 R223 R224 R225	0687-6831 0687-1011 0758-0073 0690-1041 0687-2731		3	R: fxd comp 68k ohms 10% 1/2w R: fxd comp 100 ohms 10% 1/2w R: fxd met ox 24k ohms 5% 1/2w R: fxd comp 100k ohms 10% 1w R: fxd comp 27k ohms 10% 1/2w	01121 01121 hp 01121 01121	EB6831 EB1011 GB1041 EB2731
R226 R227 R228 R229 R230	0687-6841 0727-0110 0761-0076 0686-1055 0686-2055		2 1 1	R: fxd comp 680k ohms 10% 1/2w R: fxd depc 1500 ohms 1% 1/2w R: fxd met ox 18k ohms 5% 1w R: fxd comp 1 megohm 5% 1/2w R: fxd comp 2 megohm 5% 1/2w	01121 hp hp 01121 01121	EB6841 EB1055 EB2055
R241 R242 R243 R244 R245	0687-4711 0689-1835 0690-8231 0687-2731 0687-4711		1	R: fxd comp 470 ohms 10% 1/2w R: fxd comp 18k ohms 5% 1w R: fxd comp 82k ohms 10% 1w R: fxd comp 27k ohms 10% 1/2w R: fxd comp 470 ohms 10% 1/2w	01121 01121 01121 01121 01121	EB4711 GB1835 GB8231 EB2731 EB4711
R246 R247	0687-4741 2100-0094		1 2	R: fxd comp 470k ohms 10% $1/2w$ R: var comp 50k ohms 30% 0.1w	01121 11237	EB4741 UPE 70 SPECIAL
R251 R252 R253 R254 R255 R256	0771-0006 0687-1241 0687-1041 2100-0144 0758-0006 0686-4345		1 1 2 1	R: fxd met ox 27k ohms 10% 4w R: fxd comp 120k ohms 10% 1/2w R: fxd comp 100k ohms 10% 1/2w R: var comp 250k ohms 30% 0.1w R: fxd met ox 10k ohms 5% 1/2w R: fxd comp 430k ohms 5% 1/2w	hp 01121 01121 11237 hp 01121	EB1241 EB1041 UPE 70 EB4345

Table 6-2. Replaceable Parts (Cont'd)

Ref	hp Part No.	RS	TO	Description	Mfr	Mfr Part No.
Desig			- 46	(See Table 6-1.)		
R257 R258 R259	0758-0073 2100-0093 0687-2731		1	R: fxd met ox 24k ohms 5% 1/2w R: var comp 20k ohms 20% 0.1w R: fxd comp 27k ohms 10% 1/2w	hp 11237 01121	OBD EB2731
R261 R262 R263 R264 R265	0687-1051 0727-0376 0727-0173 0727-0285 0757-0128		6 1 1 1 1 1	R: fxd comp 1 megohm 10% 1/2w R: fxd depc 1.98 megohm 1% 1/2w R: fxd depc 20k ohms 1% 1/2w R: fxd depc 1.8 megohm 1% 1/2w R: fxd met flm 200k ohms 1% 1/2w	01121 hp hp hp hp	EB1051
R266 R267 R268 R269 R270	0687-4731 2100-0094 0727-0132 0727-0100 0687-6841		1 1	R: fxd comp 47k ohms 10% 1/2w R: var comp 50k ohms 30% 0.1w R: fxd depc 4000 ohms 1% 1/2w R: fxd depc 1000 ohms 1% 1/2w R: fxd comp 680k ohms 10% 1/2w	01121 11237 hp hp 01121	EB4731 UPE 70 SPECIAL . EB6841
R271 R272 R273 R274 R275A/B	0727-0292 0727-0292 0727-0292 0727-0292 2100-0338		1	R: fxd depc 3 megohm 1% 1/2w R: var comp log dual 100k ohms 20% 1/4w (includes \$103)	hp hp hp hp	OBD
R276 R277 R278 R279	0687-3931 0687-2231 0687-2741 0687-1541		1	R: fxd comp 39k ohms 10% 1/2w R: fxd comp 22k ohms 10% 1/2w R: fxd comp 270k ohms 10% 1/2w R: fxd comp 150k ohms 10% 1/2w	01121 01121 01121 01121	EB3931 EB2231 EB2731 EB1541
R301 R302 R303 R304 R305	0687-1021 0687-1041 0693-1541 0690-5641 0687-1051		2 1 1	R: fxd comp 1000 ohms 10% 1/2w R: fxd comp 100k ohms 10% 1/2w R: fxd comp 150k ohms 10% 2w R: fxd comp 560k ohms 10% 1w R: fxd comp 1 megohm 10% 1/2w	01121 01121 01121 01121 01121	EB1021 EB1041 HB1541 GB5641 EB1051
R306 R307 R308 R309 R310	0687-1551 0686-2455 2100-0096 0693-5651 0693-5651		1 1 1 3	R: fxd comp 1.5 megohm 10% 1/2w R: fxd comp 2.4 megohm 5% 1/2w R: var comp 1 megohm 30% 0.1w R: fxd comp 5.6 megohm 10% 2w R: fxd comp 5.6 megohm 10% 2w	01121 01121 11237 01121 01121	EB1551 EB2455 UPE 70 SPECIAL HB 5651 HB 5651
R311 R312 R313 R314 R315	0693-5651 2100-0105 0687-5641 0687-2731 0687-6831		1	R: fxd comp 5.6 megohm 10% 2w R: var comp 3.5 megohm 30% 1/2w R: fxd comp 560k ohms 10% 1/2w R: fxd comp 27k ohms 10% 1/2w R: fxd comp 68k ohms 10% 1/2w	01121 11237 01121 01121 01121	HB 5651 UPE 70 EB5641 EB2731 EB6831
R316 R317 R318 R319 R320	2100-0095 0687-6831 0687-2251 0687-3331 2100-0102		1 1 2	R: var comp 100k ohms 30% 0.1w R: fxd comp 68k ohms 10% 1/2w R: fxd comp 2.2 megohm 10% 1/2w R: fxd comp 33k ohms 10% 1/2w R: var comp 500k ohms 30% 0.1w	11237 01121 01121 01121 11237	OBD EB6831 EB2251 EB3331 UPE 70 SPECIAL
R321 R322 R323 R324 R325	2100-0171 0687-1041 0693-8251 0693-8251 0693-8251		3	R: var comp 200k ohms 20% 1/4w (includes S301) R: fxd comp 100k ohms 10% 1/2w R: fxd comp 8.2 megohm 10% 2w R: fxd comp 8.2 megohm 10% 2w R: fxd comp 8.2 megohm 10% 2w	11237 01121 01121 01121 01121	VF-45 EB1041 HB8251 HB8251 HB8251

Table 6-2. Replaceable Parts (Cont'd)

Ref Desig	hp Part No.	RS	TQ	Description (See Table 6-1.)	Mfr	Mfr Part No.
R326 R327	0687-4731 0687-2751		1	R: fxd comp 47k ohms 10% 1/2w R: fxd comp 2.7 megohm 10% 1/2w	01121 01121	EB4731 EB2751
R331 R332 R333 R334 R335	0687-1051 0687-1051 0690-1841 0690-4741 0687-1051		1	R: fxd comp 1 megohm 10% 1/2w R: fxd comp 1 megohm 10% 1/2w R: fxd comp 180k ohms 10% 1w R: fxd comp 470k ohms 10% 1w R: fxd comp 1 megohm 10% 1/2w	01121 01121 01121 01121 01121	EB1051 EB1051 GB1841 GB4741 EB1051
R336 R337 R338 R339 R340	0687-4731 0687-4711 0687-1021 0727-0236 0727-0218		1	R: fxd comp 47k ohms 10% 1/2w R: fxd comp 470 ohms 10% 1/2w R: fxd comp 1000 ohms 10% 1/2w R: fxd depc 360k ohms 10% 1/2w R: fxd depc 180k ohms 1% 1/2w	01121 01121 01121 hp hp	EB4731 EB4711 EB1021
R341 R342	0727-0378 0687-4711		1	R: fxd depc 257.1k ohms 1% 1/2w R: fxd comp 470 ohms 10% 1/2w	hp 01121	EB4711
R351 R352 R353 R354 R355	0727-0287 2100-0144 0727-0289 0687-8241 0687-8231		1 1 1 1 1	R: fxd depc 2 megohm 1% 1/2w R: var comp 250k ohms 30% 0.1w R: fxd depc 2.52 megohm 1% 1/2w R: fxd comp 820k ohms 10% 1/2w R: fxd comp 82k ohms 10% 1/2w	hp 11237 hp 01121 01121	UPE 70 EB8241 EB8231
R356 R357 R358 R359	0761-0006 0687-1831 0687-1531 0687-1051		1	R: fxd met ox 10k ohms 5% 1w R: fxd comp 18k ohms 10% 1/2w R: fxd comp 15k ohms 10% 1/2w R: fxd comp 1 megohm 10% 1/2w	hp 01121 01121 01121	EB1831 EB1531 EB1051
R361 R362 R363 R364A/B R365	0699-0006 0699-0006 0767-0010 2100-0150 0687-3331		1 1	R: fxd comp 4.7 ohms 10% 1w R: fxd comp 4.7 ohms 10% 1w R: fxd met ox 15k ohms 5% 3w R: var comp dual 10k ohms 20% 1/4w R: fxd comp 33k ohms 10% 1/2w	01121 01121 hp 11237 01121	GB47G1 GB47G1 UPE 70 EB3331
S1 S2 S3A/B/C	3101-0011 3101-0010		3	S: slide dpdt (p/o A3) NSR: part of A2 S: pushbutton dpdt	82389 82389	11A-1013 3S-1407
S101 S102 S103	3101-0011 3101-0011			S: slide dpdt (p/o A102) S: slide dpdt (p/o A101) NSR: part of R275A/B	82389 82389	11A-1013 11A-1013
S201 S202				NSR: part of A201 NSR: part of R213		
S204				NSR: part of A204		
S301				NSR: part of R321		
T301 T302	120 A-11A- 1 9100-0156		1 1	T: high voltage T: power	hp 98734	6-1691

Table 6-2. Replaceable Parts (Cont'd)

	ıω	TQ	Description (See Table 6-1.)	Mfr	Mfr Part No.
1932-0029 1932-0029 1932-0035 2140-0084 2140-0084		5 3 6	V: electron dual triode 12AU7 V: electron dual triode 12AU7 V: electron dual triode 6DJ8 V: glow lamp aged V: glow lamp aged	hp hp hp 74276 74276	A092 A092
1932-0029 1932-0035			V: electron dual triode 12AU7 V: electron dual triode 6DJ8	hp hp	
1932-0035 1933-0014 1932-0029 1921-0005 1933-0014		3	V: electron dual triode 6DJ8 V: electron triode - pentode 6GH8A V: electron dual triode 12AU7 V: electron triode 6C4 V: electron triode - pentode 6GH8A	hp hp hp hp hp	
2140-0084 2140-0084 2140-0084 2140-0084			V: glow lamp aged V: glow lamp aged V: glow lamp aged V: glow lamp aged	74276 74276 74276 74276	A092 A092 A092 A092
1932-0029 1923-0018 1920-0001 1920-0001 5083-0353		1 2 1	V: electron dual triode 12AU7 V: electron beam power pentode 6AQ5 V: electron high voltage diode 5642 V: electron high voltage diode 5642 CRT: P31 phosphor internal graticule	hp hp hp hp	
1921-0010 1933-0014 1921-0010 1923-0021 1940-0001		2	V: electron low-mu triode 12B4A V: electron triode - pentode 6GH8A V: electron low-mu triode 12B4A V: electron pentode 6AU6 V: electron voltage reference 5651A	hp hp hp hp	
8120-0050		1	W: power cord (includes P301)	70903	CS-9941/PH-151/ 7.5 ft
1200-0062 1200-0062 1200-0062		12	XV: 9 pin minat XV: 9 pin minat XV: 9 pin minat	71785 71785 71785	121-51-11-060 121-51-11-060 121-51-11-060
1200-0062 1200-0062			XV: 9 pin minat XV: 9 pin minat	71785 71785	121-51-11-060 121-51-11-060
1200-0062 1200-0062 1200-0062 1200-0053 1200-0062		4	XV: 9 pin minat XV: 9 pin minat XV: 9 pin minat XV: 7 pin minat XV: 9 pin minat	71785 71785 71785 71785 71785 71785	121-51-11-060 121-51-11-060 121-51-11-060 121-51-11-069 121-51-11-060
	1932-0029 1932-0035 2140-0084 2140-0084 1932-0029 1932-0035 1932-0035 1933-0014 1932-0029 1933-0014 2140-0084 2140-0084 2140-0084 2140-0084 2140-0084 2140-0081 1932-0029 1923-0011 1920-0001 1920-0001 1920-0001 1920-0001 1920-0001 1920-0002 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062	1932-0029 1932-0035 2140-0084 2140-0084 1932-0029 1932-0035 1933-0014 1932-0029 1921-0005 1933-0014 2140-0084 2140-0084 2140-0084 2140-0084 2140-0081 1932-0029 1923-0018 1920-0001 1920-0001 1920-0001 1920-0001 1920-0001 1920-0001 1920-0002 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062	1932-0029 1932-0035 2140-0084 2140-0084 1932-0029 1932-0035 1932-0035 1933-0014 1932-0029 1921-0005 1933-0014 2140-0084 2140-0084 2140-0084 2140-0084 2140-0081 1922-0001 1923-0018 1920-0001 1920-0001 1920-0001 1920-0001 1923-001 1921-010 1923-0021 1940-0001 1 8120-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062 1200-0062	1932-0025 3 V: electron dual triode 6DJ8 V: glow lamp aged V: glow lamp aged V: electron dual triode 6DJ8 V: electron dual dual dual dual dual dual dual dual	1932-0025 3 V: electron dual triode 12AU7 hp hp 74276

Table 6-2. Replaceable Parts (Cont'd)

Ref Desig	hp Part No.	RS	TQ	Description (See Table 6-1.)	Mfr	Mfr Part No.
XV301	1200-0062			XV: 9 pin minat	71785	121-51-11-060
KV302	1200-0053			XV: 7 pin minat	71785	111-51-11-069
CV305	1200-0037	1		NSR - consists of: Socket: crt	la ca	
	1200-0050			Pin: crt socket	hp hp	
	1200-0192			Cover: crt socket	hp	
CV307	1200-0062			XV: 9 pin minat	71785	121-51-11-060
CV308 CV309	1200-0062 1200-0062		1	XV: 9 pin minat XV: 9 pin minat	71785	121-51-11-060
CV310	1200-0053			XV: 7 pin minat	71785 71785	121-51-11-060 111-51-11-069
CV311	1200-0053			XV: 7 pin minat	71785	111-51-11-069
XQ301	1200-0041		1	XQ: 2 pin	71785	133-92-10-034
				MISCELLANEOUS		
	0370-0026		2	Knob: 3/4 inch black w/arrow	hp	
	0370-0037		2	Knob: 1 inch skirted black w/arrow	hp	
	0370-0062		2	Knob: 3/4 inch red w/arrow	hp	
	0370-0084 0370-0113		2 1	Knob: 5/8 inch black w/arrow Knob: 3/4 inch skirted black w/arrow	hp	
	0010-0113		1	Thiob, by I men skitted black w/arrow	hp	
	0370-0114		1	Knob: 5/8 inch red w/arrow	hp	
	0905-0016		1	Gasket: felt (crt)	hp	202011
	1200-0043 1205-0003		1 1	Insulator: anodized alum (for Q301) Insulator: transistor (Q301)	76530 hp	293011
	1205-0007		1	Dissipator: heat (nut)	hp	
	1205-0008		1	Digginatory hoat (hody)	hun	
	5000-0408		3	Dissipator: heat (body) Bracket: coil alignment	hp hp	
	5040-0401	1	7	Support: hy capacitor	hp	
	5040-0421		1	Insulator: hv (intensity pot)	hp	
	5040-0466		1	Retainer: crt shield	hp	
	120A-20A		1	Bezel: crt	hp	
	120B-1A		1	Deck: main	hp	
	120B-1B 120B-5A		1 1	Deck: capacitor	hp	
	120B-5A 120B-6D		1	Bracket: angle center Shield: sync	hp hp	
				·	1	
	120B-16B		1	Cable: vertical input	hp	
	120B-6F 120B-16F		1 1	Assy: crt shield Cable: main harness	hp hp	
	120B-10F		1	Support: pc board stiffener	hp	
				SPECIAL ORDER CRT'S		
	5083-0323			CRT: P2 phosphor internal graticule	hp	
	5083-0333			CRT: P7 pyosphor internal graticule	hp	
	5083-0342			CRT: P11 phosphor aluminized internal graticule	hp	
				OPTION 05		
				(Parts required in addition to, or instead of, standard parts.)		
	0693-4711		1	R: fxd comp 470 ohms 10% 2w	hp	
	1370-0084		1	Knob: 5/8 inch black w/arrow	hp	
	1450-0084		4	Lampholder: screw base miniature	hp	
	2100-1838		1	R: var comp 300 ohms 20% 1w, with spst switch	hp	1770
	2140-0057		4	Lamp: 6 v incd miniature screw base	24455	1768

Table 6-2. Replaceable Parts (Cont'd)

			OPTION 05 (cont'd)		
5040-0420 5083-0310 5083-0320 5083-0330 5083-0340		1	Mask: light CRT: P1 phosphor w/o internal graticule CRT: P2 phosphor w/o internal graticule CRT: P7 phosphor w/o internal graticule CRT: P11 phosphor w/o internal graticule	hp hp hp hp	
5083-0350 9100-1108 120A-83A 120A-83B 120A-83C		1 1	CRT: P31 phosphor w/o internal graticule T: power Filter: light amber (for P7 phosphor) Filter: light blue (for P31 phosphor) Graticule: external scribed	hp hp hp hp	
120A-83G 120B-2F 120B-83C-1 120B-83E		1 1 1	Filter: light green (for P1, P2, P31 phosphor) Panel: front Graticule: external unscribed Retainer: crt	hp hp hp	
			OPTION 06		
			(Parts required in addition to, or instead of, standard parts.)		
2151-0038 2151-0040 120B-2G 120B-16J 120B-16K		2 2 1 1 1	Connector: 3 pin female Clamp: cable Panel: rear Cable: 20 inch Cable: 26 inch	71468 71468 hp hp	CA3106A10SL-3S-A105 AN3057-4
			OPTION 13		
			(Parts required in addition to, or instead of, standard parts.)		
120B-2H 120B-5B 120B-6G 120B-12P 120B-37A 120B-47A		1 2 1 2 2 2	Panel: front Casting: frame side Assy: vertical shield (A101) Assy: ac/dc switch (A3, A102) Bar: panel mounting Support: panel	hp hp hp hp hp	
	5083-0330 5083-0340 5083-0350 9100-1108 120A-83B 120A-83G 120B-2F 120B-83C-1 120B-83E 2151-0040 120B-2G 120B-16J 120B-16K	5083-0330 5083-0330 5083-0350 9100-1108 120A-83B 120A-83G 120B-2F 120B-83C-1 120B-83E 2151-0038 2151-0040 120B-2G 120B-16J 120B-16K	5083-0330 5083-0340 5083-0350 9100-1108 120A-83A 120A-83B 120A-83G 120B-2F 120B-83C-1 120B-83E 1 2151-0038 2151-0040 120B-2G 120B-16J 120B-16K 1 120B-16K 1	5083-0330 5083-0340 CRT: P7 phosphor w/o internal graticule CRT: P11 phosphor w/o internal graticule CRT: P11 phosphor w/o internal graticule CRT: P11 phosphor w/o internal graticule T: power Filter: light amber (for P7 phosphor) Filter: light blue (for P31 phosphor) Graticule: external scribed 120A-83G 120B-2F 120B-83C-1 120B-83E 1 Filter: light green (for P1, P2, P31 phosphor) Graticule: external unscribed Retainer: crt OPTION 06 (Parts required in addition to, or instead of, standard parts.) Connector: 3 pin female Clamp: cable Panel: rear 120B-16J 120B-16K OPTION 13 (Parts required in addition to, or instead of, standard parts.) OPTION 13 (Parts required in addition to, or instead of, standard parts.) Panel: rear Cable: 26 inch OPTION 13 (Parts required in addition to, or instead of, standard parts.) Applied to the capture of th	CRT: P7 phosphor w/o internal graticule hp hp

Table 6-3. Code List of Manufacturers

The following code numbers are from the Federal Supply Code for Manufacturers Cataloging Handbooks H4-1 (Name to Code) and H4-2 (Code to Name) and their latest supplements. The date of revision and the date of the supplement sused appear at the bottom of each page. Alphabetical codes have been arbitrarily satigated to suppliers not appearing in the H4 handbooks.

	The bottom of each page. Alphabetical codes have been aroundarily assigned to suppliers not appearing in the nin annobods.									
Code No.	Manufacturer Address	Code No.	Monufacturer Address	Code No.	Manufacturer	Address	Code No.	Manufacturer Address		
	U.S.A. Common Any supplier of U.S.	07126	Digitran Co. Pasadena, Calif. Transistor Electronics Corp. Minneapolis, Minn.	17474 18042		ountain View, Calif. Palo Alto, Calif.		Coto Coil Co., Inc. Providence, R.I. Chicago Miniature Lamp Works Chicago, III.		
00136	McCoy Electronics Mount Holly Springs, Pa. Sage Electronics Corp. Rochester, N.Y.		Transistor Electronics Corp. Minneapolis, Minn. Westinghouse Electric Corp.		Power Design Pacific Inc. Ty-Car Mfg. Co., Inc.	Holliston, Mass.	71744	A.O. Smith Corp., Crowley Div.		
00287	Cemco Inc. Danielson, Conn.	07140	Electronic Tube Div. Elmira, N.Y. Filmohm Corp. New York, N.Y.		Radio Industries	Des Plaines, III. Mt. Kisco, N.Y.		West Orange, N.J.		
	Humidial Colton, Calif. Garlock Inc.		Filmohm Corp. New York, N.Y. Cinch-Graphik Co. City of Industry, Calif.		Curtis Instrument, Inc. E. I. DuPont and Co., Inc.	Mt. Kisco, N.Y. Wilmington, Del.	/1/85	Cinch Mfg. Co., Howard B. Jones Div. Chicago, III.		
	Electronics Products Div. Canden, N. J.	07261	Avnet Corp. Los Angeles, Calif.	18911	Durant Mig. Co.	Milwaukee, Wis.	71984	Dow Corning Corp. Midland, Mich.		
00656	Aerovox Corp. New Bedford, Mass. Amp, Inc. Harrisburg, Pa.	0/263	Fairchild Camera & Inst. Corp. Semiconductor Div. Mountain View, Calif.		Bendix Corp., The Eclipse-Poineer Div.	Teterboro, N.J.	72136 72354	Electro Motive Mig. Co., Inc. Willimantic, Conn. John E. Fast Co., Div. Victoreen Instr. Co.		
00781	Aircraft Radio Corp. Boonton, N.J.		Minnesola Rubber Co. Minneapolis, Minn.	19500	Thomas A. Edison Industries, McGraw-Edison Co.			Chicago, III.		
00815	Northern Engineering Laboratories, Inc. Burlington, Wis.	07700	Birtcher Corp., The Monterey Park, Calif. Technical Wire Products Inc. Cranford, N. J.	19644		West Orange, N.J. Horseheads, N.Y.		Dialight Corp. Brooklyn, N.Y Indiana General Corp., Electronics Div.		
00853	Sangamo Electric Co., Pickens Div.		Continental Device Corp. Hawthorne, Calif.	19701	Electra Mfg. Co. In General Atronics Corp.	dependence, Kansas Philadelphia, Pa.		Keasby, N.J.		
nnece	Pickens, S. C. Goe Engineering Co. Los Angeles, Calif.	0/933	Semiconductor Div. Mountain View, Calif.		Executone, Inc.	New York, N.Y.	72765	Drake Mfg. Co. Chicago, III. Hugh H. Eby Inc. Philadelphia, Pa.		
00891	Carl E. Holmes Corp. Los Angeles, Calif.	07966	Shockley Semi-Conductor Laboratories	21335	Fafnir Bearing Co., The	New Britain, Conn.	72928	Gudeman Co. Chicago, III.		
	Allen Bradley Co. Milwaukee, Wis. Litton Industries, Inc. Beverly Hills, Calif.	07980	Palo Alto, Calif. Hewlett-Packard Co., Boonton Radio Div.	21520	Fansteel Metallurgical Corp. G.E. Lamp Division	N. Chicago, III.	72964	Robert M. Hadley Co. Los Angeles, Calif. Erie Technological Products, Inc. Erie, Pa.		
01281	TRW Semiconductors, Inc. Lawndale, Calif.		Rockaway, N.J.		Nela Pa	ark, Cleveland, Ohio	73061	Hansen Mfg. Co., Inc. Princeton, Ind.		
01295	Texas Instruments, Inc., Transistor Products Div. Dallas, Texas	08145	U.S. Engineering Co. Los Angeles, Calif. Blinn, Delbert Co. Pomona, Calif.			West Concord, Mass. New Rochelle, N.Y.	73076	H.M. Harper Co. Chicago, III. Helipot Div. of Beckman Inst., Inc.		
	The Alliance Mfg. Co. Alliance, Ohio	08358	Burgess Battery Co.		Grobet File Co. of America, In	nc.		Fullerton, Calif.		
01589	Pacific Relays, Inc. Van Nuys, Calif. Amerock Corp. Rockford, III.	08664	Niagara Falls, Ontario, Canada Bristol Co., The Waterbury, Conn.	26992	Hamilton Watch Co.	Carlstadt, N.J. Lancaster, Pa.	/3293	Hughes Products Division of Hughes Aircraft Co. Newport Beach, Calif.		
01961	Pulse Engineering Co. Santa Clara, Calif.	08717	Sloan Company Sun Valley, Calif.		Hewlett-Packard Co.	Palo Alto, Calif.	73445	Amperex Electronic Co., Div. of North American		
	Ferroxcube Corp. of America Saugerties, N.Y. Cole Rubber and Plastics Inc. Sunnyvale, Calif.	08718	ITT Cannon Electric Inc., Phoenix Div. Phoenix, Arizona	33173 35434	G.E. Receiving Tube Dept. Lectrohm Inc.	Owensboro, Ky. Chicago, III.	73506	Phillips Co., Inc. Hicksville, N.Y. Bradley Semiconductor Corp. New Haven, Conn.		
02660	Amphenol-Borg Electronics Corp. Chicago, III.	08792	CBS Electronics Semiconductor	36196	Stanwyck Corl Products Ltd.		73559	Carling Electric, Inc. Hartford, Conn		
02735	Radio Corp. of America, Semiconductor and Materials Div. Somerville, N.J.		Operations, Div of C. B. S. Inc. Lowell, Mass.	37942	P. R. Mallory & Co. Inc.	ury, Ontario, Canada Indianapolis, Ind.	/3682	George K. Garrett Co., Div. MSL Industries Inc. Philadelphia, Pa.		
02771	Vocaline Co. of America, Inc.		Mel-Rain Indianapolis, Ind.	39543	Mechanical Industries Prod. Co	o. Akron, Ohio		Federal Screw Products Inc. Chicago, III.		
02777	Old Saybrook, Conn. Hopkins Engineering Co. San Fernando, Calif.		Babcock Relays Div. Costa Mesa, Calif. Texas Capacitor Co. Houston, Texas	42190	Miniature Precision Bearings, Muter Co.	Inc. Keene, N.H. Chicago, III.	73743	Fischer Special Mfg. Co. Cincinnati, Ohio General Industries Co., The Elyria, Ohio		
	G. E. Semiconductor Prod. Dept. Syracuse, N.Y.	09145	Atohm Electronics Sun Valley, Calif.	43990	C. A. Norgren Co.	Englewood, Colo.	73846	Goshen Stamping & Tool Co. Goshen, Ind		
	Apex Machine & Tool Co. Dayton, Ohio Eldema Corp. Compton, Calif.	09250 09569	Electro Assemblies, Inc. Chicago, III. Mallory Battery Co. of		Ohmite Mfg. Co. Polaroid Corp.	Skokie, III. Cambridge, Mass.	73899	JFD Electronics Corp. Brooklyn, N.Y. Jennings Radio Mfg. Corp. San Jose, Calif.		
03877	Transitron Electric Corp. Wakefield, Mass.		Canada, Ltd. Toronto, Ontario, Canada		Precision Thermometer & Inst.	Co.	74276	Signalite Inc. Neptune, N. J		
03888	Pyrofilm Resistor Co., Inc. Cedar Knoffs, N.J. Singer Co., Diehl Div.	10214	General Transistor Western Corp. Los Angeles, Calif.	49956	Microwave & Power Tube Div.	Southampton, Pa. Waitham, Mass.		J. H. Winns, and Sons Winchester, Mass. Industrial Condenser Corp. Chicago, III.		
	Finderne Plant Sumerville, N.J.	10411	Ti-Tal, Inc. Berkeley, Calif.	52090	Rowan Controller Co.	Westminster, Md.	74868	R. F. Products Division of Amphenol-Borg		
04009	Arrow, Hart and Hegeman Elect. Co. Hartford, Conn.		Carborundum Co. Niagara Falls, N.Y. CTS of Berne, Inc. Berne, Ind.	52983 54294	Sanborn Company Shallcross Mfg. Co.	Waltham, Mass. Selma, N.C.	74970	Electronics Corp. Danbury, Conn E. F. Johnson Co. Waseca, Minn		
04013	Taurus Corp. Lambertville, N.J.	11237	Chicago Telephone of California, Inc.	55026	Simpson Electric Co.	Chicago, III.	75042	International Resistance Co. Philadelphia, Pa		
	Elmenco Products Co. New York, N.Y. Hi-Q Division of Aerovox Myrtle Beach, S.C.	11242	So. Pasadena, Calif. Bay State Electronics Corp. Waltham, Mass.	55933	Sonotone Corp. Raytheon Co. Commercial App	Elmsford, N.Y.		James Knights Co. Sandwich, III. Kufka Electric Corporation Mt. Vernon, N. Y		
04354	Precision Paper Tube Co. Chicago, III.	11312	Microwave Electronics Corp. Palo Alto, Calif.		Systems Div.	So. Norwalk, Conn	75818	Lenz Electric Mfg. Co. Chicago, III.		
04404	Dymec Division of Hewlett-Packard Co. Palo Alto, Calif.		Duncan Electronics Inc. Costa Mesa, Calif. General Instrument Corp., Semiconductor		Spaulding Fibre Co., Inc. Sprague Electric Co.	Tonawanda, N.Y. North Adams, Mass.		Littlefuse, Inc. Des Plaines, III. Lord Mfe. Co. Erie. Pa		
04651	Sylvania Electric Products, Microwave		Div., Products Group Newark, N.J.	59446	Telex, Inc.	St. Paul, Minn.	76210	C.W. Marwedel San Francisco, Calil		
0.4212	Device Div. Mountain View, Calif. Motorola, Inc., Semiconductor Prod. Div.		Imperial Electronic, Inc. Buena Park, Calif Melabs, Inc. Palo Alto, Calif.		Thomas & Betts Co. Triplett Electrical Inst. Co.	Elizabeth, N.J. Bluffton, Ohio	76433	General Instrument Corp., Micamold Div Newark, N.J		
	Phoenix, Arizona	12136	Philadelphia Handle Co. Camden, N. J.		Union Switch and Signal, Div.	of	76487	James Millen Mfg. Co., Inc. Malden, Mass		
04732	Fitron Co., Inc. Western Div. Culver City, Calif.		Clarostat Mfg. Co. Dover, N. H. Nippon Electric Co., Ltd. Tokyo, Japan	62119	Westinghouse Air Brake Co Universal Electric Co	Pittsburgh, Pa. Owosso, Mich.	76493	J.W. Miller Co Los Angeles, Calil Monadnock Mills San Leandro, Calif		
	Automatic Electric Co. Northlake, III.	12881	Metex Electronics Corp. Clark, N. J.	63743	Ward-Leonard Electric Co.	Mt. Vernon, N.Y.	76545	Mueller Electric Co Cleveland, Ohio		
	Sequoia Wire Co. Redwood City, Calif. Precision Coil Spring Co. El Monte, Calif.	12930	Delta Semiconductor Inc. Newport Beach, Calif. Dickson Electronics Corp. Scottsdale, Arizona	64959 65092	Western Electric Co., Inc Weston Inst. Inc. Weston-News	New York, N.Y. ark Newark, N.J.		Oak Manufacturing Co Crystal Lake, III		
04870	P.M. Motor Company Westchester, III.	13103	Thermolloy Dallas, Texas	66295	Wittek Mfg. Co.	Chicago, III.		Bendix Corp., The Bendix Pacific Div. N. Hollywood, Calif		
05006	Twentieth Century Plastics, Inc. Los Angeles, Calif.		Telefunken (GmbH) Hanover, Germany Midland-Wright Div. of Pacific Industries, Inc.	66346	Revere Wollansak Div. Minn. I Mft. Co.	Mining & St. Paul, Minn.	77075	Pacific Metals Co. San Francisco, Calif Phanostran Instrument and Electronic Co		
05277	Westinghouse Electric Corp.		Kansas City, Kansas	70276	Allen Mfg. Co.	Hartford, Conn		South Pasadena, Calif		
05347	Semi-Conductor Dept. Youngwood, Pa. Ultronix, Inc. San Mateo, Calif.	14099	Sem-Tech Newbury Park, Calif. Calif. Resistor Corp. Santa Monica, Calif.	70318	Alimetal Screw Product Co., I	Inc Garden City, N.Y.	77252	Philadelphia Steel and Wire Corp Philadelphia, Pa		
05593	Illumitronic Engineering Co. Sunnyvale, Calif.	14298	American Components, Inc. Conshohocken, Pa.		Atlantic India Rubber Works, I	inc. Chicago, III	77342	American Machine & Foundry Co. Poller		
05616	Cosmo Plastic (c/o Electrical Spec. Co.) Cleveland, Ohio	14433	ITT Semiconductor, A Div. of Int. Telephone & Telegraph Corp. West Palm Beach, Fla.		Amperite Co., Inc. Belden Mfg. Co.	Union City, N.J. Chicago, III	77630	& Brumfield Div. Princeton, Ind TRW Electronic Components Div. Camden, N.J.		
	Barber Colman Co. Rockford, III.		Hewlett-Packard Company Loveland, Colo	70998	Bird Electronic Corp.	Cleveland, Ohio		General Instrument Corp., Rectifier Div		
05728	Tiffen Optical Co. Roslyn Heights, Long Island, N.Y.		Cornell Dublier Electric Corp. Newark, N.J. Corning Glass Works Corning, N.Y.		Birnbach Radio Co. Boston Gear Works Div. of Mui	New York, N.Y	77764	Resistance Products Co. Harrisburg, Pa		
	Metro-Tel Corp. Westbury, N.Y.	14752	Electro Cube Inc. So. Pasadena, Calif.		of Texas	Quincy, Mass.	77969	Rubbercraft Corp. of Calif. Torrance, Calif		
	Stewart Engineering Co. Santa Cruz, Calif. Wakefield Engineering Inc. Wakefield, Mass.	14960	Williams Mfg. Co. San Jose, Calif. Webster Electronics Co. New York, N. Y.	71218	Bud Radro, Inc. Camioc Fastener Corp.	Willoughby, Ohio Paramus, N. J.	78189	Shakeproof Division of Illinois Tool Works Elgin, III		
06004	Bassick Co., The Bridgeport, Conn.	15291	Adjustable Bushing Co. N. Hollywood, Calif.	71313	Cardwell Condenser Corp			Signal Indicator Corp. New York, N. Y		
	Bausch and Lomb Optical Co. Rochester, N.Y. E.T.A. Products Co. of America Chicago, III.	15558	Micron Electronics Garden City, Long Island, N.Y.	71400	Bussmann Mfg, Div. of McGra-	denhurst L.I., N.Y w-Edison Co.	78290 78452	Struthers-Dunn Inc. Pitman, N. J Thompson-Bremer & Co. Chicago, III		
06475	Western Devices Inc. Burbank, Calif.	15772	Twentieth Century Coil Spring Co.			St. Louis, Mo.	78471	Tilley Mfg. Co. San Francisco, Calif		
06540	Amatom Electronic Hardware Co., Inc. New Rochelle, N.Y.	15818	Santa Clara, Calif. Amelco Inc. Mt. View, Calif	71436	Chicago Condenser Corp. Calif. Spring Co., Inc.	Chicago, III Pico-Rivera, Calif.		Stackpole Carbon Co. St. Marys, Pa Standard Thomson Corp. Waltham, Mass		
06555	Beede Electrical Instrument Co., Inc.		Daven Div. Thomas A. Edison Ind.	71450	CTS Corp.	Elkhart, Ind.	78553	Tinnerman Products, Inc. Cleveland, Ohio		
05555	Penacook, N.H. General Devices Co., Inc. Indianapolis, Ind.	16037	McGraw-Edison Co. Long Island City, N. Y Spruce Pine Mica Co. Spruce Pine, N. C		ITT Cannon Electric Inc Cinema Plant, Hi-Q Div Aero	Los Angeles, Cairf	78790 78947	Transformer Engineers San Gabriel, Calif Ucinite Co Newtonville, Mass		
	Nuclear Corp. of America	16179	Omni-Spectra Inc. Detroit, III			Burbank, Calif	79136	Waldes Kohinoor Inc Long Island City, N.Y		
06813	U.S. Semcor Div. Phoenix, Arizona ! Torrington Mfg. Co., West Div.		Computer Diode Corp. Lodi, N.J. Ideal Prec. Meter Co., Inc.	71482	C.P. Clare & Co. Centralab Div. of Globe Union	Chicago, III		Veeder Root, Inc Hartford, Conn Wenco Mfg. Co Chicago, III,		
	Van Nuys, Calif.		De Jur Meter Div. Brooklyn, N. Y			Milwaukee, Wis	19727	Continental-Wirt Electronics Corp		
	Eitel-McCullough Inc. San Carlos, Calif. Kelvin Electric Co. Van Nuys, Calif.		Delco Radio Div. of G.M. Corp. Kokomo, Inc. Thermonetics Inc. Canoga Park, Calif		Commercial Plastics Co Cornish Wire Co., The	Chicago, III New York, N. Y	79963	Philadelphia, Pa Zierick Mfg. Corp New Rochelle, N. Y		
0,000										

00015-41 Revised: November, 1965

Table 6-3. Code List of Manufacturers (Cont'd)

Code		Code		Code			Code		
No.	Manufacturer Address	No.	Manufacturer Address	No.	Manufacturer	Address	No.	Manufacturer	Address
81349	Mulitary Specification		R.M. Bracamonte & Co. San Francisco, Calif.		G. V Controls	Livingston, N J.		Francis L. Mosley	Pasadena, Calif.
	Wilker Products, Inc. Cleveland, Ohio		Koiled Kords, Inc. New Haven, Conn.	93983	Insuline-Van Norman Ind., Inc.			Microdot, Inc.	So. Pasadena, Calif.
	Raytheon Mig. Co., Industria Components		Seamless Rubber Co. Chicago, III.		Electionic Division	Manchester, N.H.		Sealectro Corp.	Mamaroneck, N.Y.
	Div Industr Tube Operations Newton Mass		Clifton Precision Products Clifton Heights, Pa.		General Cable Corp.	Bayonne, N.J.		Carad Corp.	Redwood City, Calif.
81483	International Rectifier Corp. El Segundo, Calif.		Precision Rubber Products Corp. Dayton, Ohio	94144	Raytheon Mig. Co., Industrial C		98731		Minneapolis, Minn.
81541	The Airpax Products Co. Cambridge, Mass.	86684	Radio Corp. of America, RCA		Div Receiving Tube Operati			North Hills Electric Co.	Mineola, N.Y.
81860	Barry Controls, Inc. Watertown, Mass.		Electron Tube Div. Harrison, N. J.	94145	Raytheon Mfg. Co., Semiconduc		98925	Clevite Transistor Prod.	
82042	Carter Parts Co. Skokie, III.	8/216	Philos Corporation (Lansdale Division) Lansdale Pa.		California Street Plant	Newton, Mass.	00030	Div. of Clevite Corp.	Waltham, Mass.
82142	Jeffers Electronics Division of			94148	Scientific Radio Products Inc		38378	International Electronic	0.14
	Speer Carbon Co. Du Bois, Pa.	8/4/3	Western Fibrous Glass Products Co.	04164	T C-1 Electric 1	Loveland, Colo.	00100	Research Corp. Columbia Technical Corp.	Burbank, Calif,
	Allen B OuMont Labs Inc Clifton N J	0.300.4	San Francisco, Calif.		Tung-Sol Electric, Inc.	Newark, N.J.		Varian Associates	New York, N.Y.
	Maguire Industries Inc. Greenwich, Conn.		Van Waters & Rogers Inc. Seattle, Wash, Tower Mfg, Corp Providence, R 1.	94197	Curtiss-Wright Corp.,	- Determine M. A.		Marshall Industries, Electron	Palo Alto, Calif.
82219	Sylvania Electric Prod. Inc.			04222		ast Paterson, N.J. Lester, Pa.	33212		
	Electronic Tube Div. Emporium, Pa.		Cutler-Hammer, Inc. Lincoln, III.		Southco Div of S. Chester Corp	. Lester, Pa.	00707	Products Division	Pasadena, Calif.
	Astron Co. East Newark, N. J.		Gould-National Batteries, Inc. St. Paul, Minn. General Mills, Inc. Buffalo, N. Y.	94310	Tru Ohm Prod. Div. of Model	a	99/0/	Control Switch Division, Co.	
	Switchcraft, Inc. Chicago, III.		General Mills, Inc. Buffalo, N.Y. Graybar Electric Co. Dakland, Calif.	04220	Engineering and Mfg. Co. Wire Cloth Products Inc.	Chicago, III. Chicago, III.	00000	of America	El Segundo, Calif.
82647	Metals and Controls, Inc., Div. of							Delevan Electronics Corp.	East Aurora, N.Y.
	Texas Instruments, Inc.,		Waides Kohinoor, Inc. Cambridge, Mass.	94682	Worcester Pressed Aluminum Co			Wilco Corporation	Indianapolis, Ind.
	Spencer Prods. Attleboro, Mass.	89473	General Electric Distributing Corp.	01000		Worcester, Mass.		Renbrandt, Inc.	Boston, Mass.
	Research Products Corp. Madison, Wis.		Schenectady, N Y		Philbrick Researchers, Inc.	Boston, Mass.	99947	Hoffman Semiconductor Div.	
	Rotron Manufacturing Co., Inc. Woodstock, N.Y.	89636	Carter Parts Div. of Economy Baler Co.		Allies Products Corp.	Miami, Fla.	00067	Holfman Electronics Corp	. Evanston, III.
	Vector Electronic Co. Glendale, Calif.		Chicago, III.		Continental Connector Corp.	Woodside, N.Y.	33337	Technology Instrument Corp of Calif.	N
	Western Washer Mfr. Co. Los Angeles, Calif.		United Transformer Co. Chicago, III.		Leecraft Mfg. Co., Inc.	New York, N.Y.		or calli.	Newbury Park, Calif.
	Carr Fastener Co. Cambridge, Mass.	90179	U.S. Rubber Co. Mechanical		Lerco Electronics, Inc. National Coil Co.	Burbank, Calif.	THE	FOLLOWING H-P VENDO	DC HAVE NO MIN
83086	New Hampshire Ball Bearing, Inc.	00010	Goods Div. Passaic, N.J.			Sheridan, Wyo.		ASSIGNED IN THE LATES	
	Peterborough, N.H.		Bearing Engineering Co. San Francisco, Calif.		Vitramon, Inc.	Bridgeport, Conn.		FEDERAL SUPPLY COD	
	Pyramid Electric Co. Darlington, S.C.		Connor Spring Mfg. Co. San Francisco, Calif. Miller Dial & Nameplate Co. El Monte, Calif.		Gordas Corp. Methode Mfg. Co.	Bloomfield, N.J.		ERS HANDBOOK.	E FUR MANUFAC
	Electro Cords Co. Los Angeles, Calif.				Dage Electric Co., Inc.	Chicago, III. Franklin, Ind.	TORE	INS HANDBOOK.	
	Victory Engineering Corp. Springfield, N. J.		Radio Materials Co. Chicago, III. Augat Brothers', Inc. Attleboro, Mass.		Weckesser Co.		10000	Winchester Electronics, Inc.	
	Bendix Corp., Red Bank Div. Red Bank, N.J.		Augat Brothers', Inc. Attleboro, Mass. Dale Electronics, Inc. Columbus, Nebr.		Huggins Laboratories	Chicago, III. Sunnyvale, Calif.	10000	Willester Electronics, Hic.	Santa Monica, Calif.
	Hubbell Corp. Mundelein, III.		Elco Corp. Philadelphia, Pa.		HI-O Division of Aerovox	Olean, N.Y.	nonne	Malco Tool and Die	Los Angeles, Calif.
	Smith, Herman H., Inc. Brooklyn, N.Y.		Gremar Mfg. Co., Inc. Wakefield, Mass.		Thordarson-Meissner Div. of	Olean, N. 1.		Western Corl Div. of Automa	
	Central Screw Co. Chicago, III.		K F Development Co. Redwood City, Calif.	30230	Maguire Industries, Inc.	Mt. Carmel, III,	00000	Ind., Inc.	Redwood City, Calif.
83501	Gavitt Wire and Cable Co.,		Minneapolis-Honeywell Regulator Co.	95.795		os Angeles, Calif.	nnnnp	Ty-Car Mfg. Co., Inc.	Holliston, Mass.
	Div. of Amerace Corp. Brookfield, Mass.	21 32 3	Microswitch Div. Freeport, III.		Cariton Screw Co.	Chicago, III.		Willow Leather Products Con	
83594	Burroughs Corp.,	01001	Nahm-Bros. Spring Co. Oakland, Calif.		Microwave Associates, Inc.	Burlington, Mass.		British Radio Electronics L1	
	Electronic Tube Div. Plainfield, N.J.		Tru-Connector Corp. Peabody, Mass.		Excel Transformer Co.	Oakland, Calif.		B ETA	Englan
	Eveready Battery New York, N.Y.		Universal Metal Prod., Inc. Bassett Puente, Calif.		Industrial Retaining Ring Co.	Irvington, N.J.		Indiana General Corp., Elec	
	Model Eng. and Mfg., Inc. Huntington, Ind.		Eigeel Optical Co., Inc. Rochester, N.Y.		Automatic and Precision Mfg. C			Precision Instrument Compor	
	Loyd Scruggs Co. Festus, Mo.		Tinsolite Insulated Wire Co. Tarrytown, N.Y.	31333	Automatic and Frecision mig. C	Yonkers, N.Y.	00000	riccision institutent compo	Van Nuys, Calif.
	Arco Electronis, Inc. New York, N.Y.		Sylvania Electric Prod. Inc.,	0.106.6	CBS Electronics.	Tulikers, N. I.	оломы	Rubber Eng. & Development	
	A. J. Glesener Co., Inc. San Francisco, Calif.	22335	Semiconductor Div. Woburn, Mass.	37300	Div. of C.B.S., Inc.	Danvers, Mass.		A "N" D Manufacturing Co.	
	Good All Electric Mig. Co. Ogaliala, Neb.	02260	Robbins and Myers, Inc. New York, N.Y.	02070	Reon Resistor Corp.	Yonkers, N.Y.		Cooltron	Oakland, Calif.
	Sarkes Tarzian, Inc. Bloomington, Ind.		Stevens Mfg. Co. Inc. Mansfield Ohio		Axel Brothers Inc.	Jamaica, N.Y.		Control of Elgin Watch Co.	Burbank, Calif.
	Boonton Molding Company Boonton, N. J.		Howard J. Smith Inc. Port Monmouth, N. J.		Rubber Teck, Inc.	Gardena, Calif.		California Eastern Lab.	Burlingame, Calif
854/1	A.B. Boyd Co. San Francisco, Calif.					Outdoile, Outlin			Angeles 45, Calif.
00144	ADC Products Inc. Minneapolis, Minn. Subsidiary of Magnetic Controls Co.								
01002	General Electric Co. Capacitor Dept. Gainsville, Fla.								
0539	Union Carbide Corp. Cleveland, Ohio Linde Division Kemet Dept.								
52981	Sanhara Co Walshan Mara								

 Kemet Dept.

 52983 Sanborn Co.
 Waltham, Mass.

 73586 Circle F Mfg. Co.
 Trenton, N.J.

 91886 Malco Mfg. Co., Inc.
 Chicago, III.

APPENDIX I MANUAL CHANGES

This appendix contains information on changes required to adapt this manual to an instrument with a serial prefix listed in the table below. Check for your instrument serial prefix and make the changes indicated. Note that these changes adapt the manual to cover a particular instrument as manufactured and therefore will not apply to an instrument subsequently modified in the field. Refer to Section I for information on errata in this manual and on any other instrument serial prefix not covered in this appendix.

Instrument	Make Numbered					
Serial Prefix	Changes					
502-	1					
433-	1, 2					
421-	1, 2, 3					
327-, 403-, 409-	1, 2, 3, 4					
303-	1, 2, 3, 4, 5					
242-, 247-	1, 3, 4, 5, 6					
202-, 217-, 219-, 223-	1, 3, 4, 5, 6, 7					

CHANGE 1

Page 5-16, Figure 5-7,

R108, R110: Change value to 330K.

Tables 6-1 and 6-2,

R108, R110: Change to hp Part No. 0687-3341; R: fxd, comp, 330K ohms, 10%, 1/2W; Mfr 01121; Mfr Part No. EB3341.

CHANGE 2

Tables 6-1 and 6-2,

C322A/B: Change to hp Part No. 0180-0127; C: fxd, elect 2-sect, 120 x 40 \(mu f\), -10\% +50\% 300VDCW: Mfr 56289; Mfr Part No. D36235.

CHANGE 3

Tables 6-1 and 6-2,

A1: Change to hp Part No. 120B-65A.
A202: Change to hp Part No. 120B-65B.
CR305: Change to hp Part No. 1902-0759; Mfr 04713; Mfr Part No. 1N2983B.

CHANGE 4

Page 5-17, Figure 5-8,

R207: Change value to 18K ohms.

Page 5-18, Figure 5-9,

R351: Change value to 1.88M ohms.

Tables 6-1 and 6-2,

R207: Change to hp Part No. 0687-1031; R: fxd, comp, 10K ohms, 10% 1/2W; Mfr 01121; Mfr Part No. EB1031.

R351: Change to hp Part No. 0727-0286; R: fxd, depc, 1.88M ohms, 1% 1/2W; Mfr hp.

CHANGE 5

Tables 6-1 and 6-2,

CR201: Change to hp Part No. 1901-0034; Diode: Si; Mfr 07933; Mfr Part No. DW204A.

CHANGE 6

Tables 6-1 and 6-2,

A201: Change to hp Part No. 120B-19C.

C321: Change to hp Part No. 0180-0042; C: fxd, elect, 120 μ f, 350VDCW; Mfr 56289; Mfr Part No. D3253.

C325A/B: Change to hp Part No. 0180-0030; C:fxd, elect, 2-sect, 120 x 40 μ f, 450VDCW; Mfr 56289; Mfr Part No. D32352.

MISCELLANEOUS.

Knob: TRIGGER SOURCE selector: Change to hp Part No. 0370-0099.

Knob: TRIGGER LEVEL control: Change to hp Part No. 0370-0134.

CHANGE 7

Page 5-19, Figure 5-10,

C305, C307: Change value to 6800 pf.

C308: Relocate into A302 in parallel with T301 pin 5 and plate of V303, and change value to 1500 pf.

C310: Relocate into A302 in parallel with T301 pin 9 and plate of V304, and change value to 1500 pf.

C312: Change value to .015 μf .

C313, C314: Delete.

R313: Change value to 680K ohms.

R322: Change value to 47K ohms.

R327: Change value to 1.5M ohms.

Tables 6-1 and 6-2,

A301: Change to hp Part No. 120B-65C.

A302: Change to hp Part No. 120B-11A.

C305, C307: Change to hp Part No. 0160-0110; C: fxd, paper, 6800 pf, 20% 3000VDCW; Mfr 56289; Mfr Part No. 184P682030.

C308, C310: Change to hp Part No. 0160-0061; C: fxd, paper, 1500 pf, 20% 500VDCW; Mfr 56289; Mfr Part No. 184P152050.

C312: Change to hp Part No. 0160-0062; C: fxd, paper, .015 μ f, 10% 3000VDCW; Mfr 56289; Mfr Part No. 184P153930.

C313, C314: Delete.

CR304: Change to hp Part No. 1901-0026; Diode: Si; Mfr hp.

R313: Change to hp Part No. 0687-6841; R: fxd, comp, 680K ohms, 10% 1/2W; Mfr 01121; Mfr Part No. EB6841.

R322: Change to hp Part No. 0687-4731; R: fxd, comp, 47K ohms, 10% 1/2W; Mfr 01121; Mfr Part No. EB4731.

R327: Change to hp Part No. 0687-1551; R: fxd, comp, 1.5M ohms, 10% 1/2W; Mfr 01121; Mfr Part No. EB1551.





CATHODE-RAY TUBE WARRANTY

The cathode-ray tube (CRT) supplied in your Hewlett-Packard Oscilloscope and replacement CRT's purchased from hp are warranted by the Hewlett-Packard Company against electrical failure for a period of one year from the date of sale. Broken tubes and tubes with phosphor or mesh burns are not included under this warranty. If the CRT is broken when received, a claim should be made with the responsible carrier.

Your nearest Hewlett-Packard Sales/Service Office (listed at rear of instrument manual) maintains a stock of replacement tubes and will assist in processing the warranty claim.

We would like to evaluate every defective CRT. This engineering evaluation helps us to provide a better product for you. Please fill out the CRT Failure Report on the reverse side of this sheet and return it with the defective CRT to:

Hewlett-Packard Company 1900 Garden of the Gods Road Colorado Springs, Colorado 80907

Attention: CRT QA

To avoid damage to the tube while in shipment, please follow the shipping instructions below; warranty credit is not allowed on broken tubes.

SHIPPING INSTRUCTIONS

It is preferable that the defective CRT be returned in the replacement CRT carton. If the carton or packaging material is not available, pack the CRT according to the instructions below:

- 1. Carefully wrap the tube in 1/4 inch thick cotton batting or other soft padding material.
- 2. Wrap the above in heavy kraft paper.
- Pack wrapped tube in a rigid container which is at least 4 inches larger than the tube in each dimension.
- 4. Surround the tube with at least 4 inches of packed excelsior or similar shock absorbing material; be sure the packing is tight all around the tube.

Thank you,

CRT Department



CRT WARRANTY CLAIM

FF	ROM: Date	
	NAME	
	COMPANY	
	ADDRESS	
T7 -	and division 1 information and as	
	or additional information, contact:	
	NAME	
	TITLE	
	COMPANY	
	ADDRESS	
1.	<pre> instrument a) model b) serial no</pre>	
2.	CRT a) TYPE (on bulb)	
	b) SERIAL NO. (on CRT base)	
3.	Is defective tube original. YESNO	
4.	Date purchased (if available)	
5.	Describe nature and or symptoms of trouble.	
6.	Describe operating conditions prior to and at time of failure. (Please estimate CRT "on-time" since purchase.)	



UNITED STATES

ALABAMA P.O. Box 4207 2003 Byrd Spring Road S.W. Huntsville 35802 Tel: (205) 881-4591

TWX: 810-726-2204 ARIZONA ARIZONA 3009 North Scottsdale Road Scottsdale 85251 Tel: (602) 945-7601 TWX: 910-950-1282

5737 East Broadway Tucson 85716 Tel: (602) 298-2313 TWX: 910-952-1162

CALIFORNIA 1430 East Orangethorpe Ave. Fullerton 92631 Tel: (714) 870-1000

3939 Lankershim Boulevard North Hollywood 91604 Tel: (213) 877-1282 TWX: 910-499-2170

1101 Embarcadero Road Palo Alto 94303 Tel: (415) 327-6500 TWX: 910-373-1280

2591 Carlsbad Avenue Sacramento 95821 Tel: (916) 482-1463 TWX: 910-367-2092

1055 Shafter Street San Diego 92106 Tel: (714) 223-8103 TWX: 910-335-2000 COLORADO

7965 East Prentice Englewood 80110 Tel: (303) 771-3455 TWX: 910-935-0705 CONNECTICUT 508 Tolland Street East Hartford 06108 Tel: (203) 289-9394 TWX: 710-425-3416 111 East Avenue Norwalk 06851 Tel: (203) 853-1251 TWX: 710-468-3750

DELAWARE 3941 Kennett Pike Wilmington 19807 Tel: (302) 655-6161 TWX: 510-666-2214

FLORIDA P.O. Box 545 Suite 106 9999 N.E. 2nd Avenue Miami Shores 33153 Tel: (305) 754-4565 TWX: 810-848-7262 P.O. Box 20007

P.O. Box 20007 Herndon Station 32814 621 Commonwealth Avenue Orlando Tel: (305) 841-3970 TWX: 810-850-0113

P.O. Box 8128 Madeira Beach 33708 410 150th Avenue St. Petersburg Tel: (813) 391-0211 TWX: 810-863-0366

GEORGIA P.O. Box 28234 450 Interstate North Atlanta 30328 Tel: (404) 436-6181 TWX: 810-766-4890

ILL INOIS 5500 Howard Street **Skokie** 60076 Tel: (312) 677-0400 TWX: 910-223-3613 4002 Meadows Drive Indianapolis 46205 Tel: (317) 546-4891 TWX: 810-341-3263

INDIANA

LOUISIANA P.O. Box 856 1942 Williams Boulevard Kenner 70062 Tel: (504) 721-6201 TWX: 810-955-5524

MARYLAND 6707 Whitestone Road Baltimore 21207 Tel: (301) 944-5400 TWX: 710-862-0850

2 Choke Cherry Road Rockville 20850 Tel: (301) 948-6370 TWX: 710-828-9684

MASSACHUSETTS 32 Hartwell Ave. Lexington 02173 Tel: (617) 861-8960 TWX: 710-326-6904

MICHIGAN 24315 Northwestern Highway Southfield 48075 Tel: (313) 353-9100 TWX: 810-232-1532

MINNESOTA 2459 University Avenue St. Paul 55114 Tel: (612) 645-9461 TWX: 910-563-3734 MISSOURI

9208 Wyoming Place Kansas City 64114 Tel: (816) 333-2445 TWX: 910-771-2087

2812 South Brentwood Blvd. St. Louis 63144 Tel: (314) 962-5000 TWX: 910-760-1670

NEW JERSEY W. 120 Century Road Paramus 07652 Tel: (201) 265-5000 TWX: 710-990-4951

1060 N. Kings Highway Cherry Hill 08034 Tel: (609) 667-4000 TWX: 710-892-4945

P.O. Box 8366 Station C 6501 Lomas Boulevard N.E. Albuquerque 87108 Tel: (050) 255-5586 TWX: 910-989-1665

156 Wyatt Drive Las Cruces 88001 Tel: (505) 526-2485 TWX: 910-983-0550

NEW YORK 1702 Central Avenue Albany 12205 Tel: (518) 869-8462 TWX: 710-441-8270

1219 Campville Road Endicatt 13764 Tel: (607) 754-0050 TWX: 510-252-0890 82 Washington Street Poughkeepsie 12601 Tel: (914) 454-7330 TWX: 510-248-0012

39 Saginaw Drive Rochester 14623 Tel: (716) 473-9500 TWX: 510-253-5981

1025 Northern Boulevard Roslyn, Long Island 11576 Tel: (516) 869-8400 TWX: 510-223-0811

5858 East Molloy Road Syracuse 13211 Tel: (315) 454-2486 TWX: 710-541-0482

NORTH CAROLINA P.O. Box 5188 1923 North Main Street High Point 27262 Tel: (919) 882-6873 TWX: 510-926-1516

OHIO 25575 Center Ridge Road Cleveland 44145 Tel: (216) 835-0300 TWX: 810-427-9129

3460 South Dixie Drive Dayton 45439 Tel: (513) 298-0351 TWX: 810-459-1925

OKLAHOMA 2919 United Founders Boulevard Oklahoma City 73112 Tel: (405) 848-2801 TWX: 910-830-6862

OREGON Westhills Mall, Suite 158 4475 S.W. Scholls Ferry Road Portland 97225 Tel: (503) 292-9171 TWX: 910-464-6103

PENNSYLVANIA 2500 Moss Side Boulevard Monroeville 15146 Tel: (412) 271-0724 TWX: 710-797-3650 1021 8th Avenue King of Prussia Industrial Park King of Prussia 19406 Tel: (215) 265-7000 TWX: 510-660-2670

RHODE ISLAND 873 Waterman Ave. East Providence 02914 Tel: (401) 434-5535

TEXAS
P.O. Box 1270
201 E. Arapahoe Rd.
Richardson 75080
Tel: (214) 231-6101
TWX: 910-867-4723

P.O. Box 22813 4242 Richmond Avenue Houston 77027 Tel: (713) 667-2407 TWX: 910-881-2645 GOVERNMENT CONTRACT OFFICE 225 Billy Mitchell Road San Antonio 78226 Tel: (512) 434-4171 TWX: 910-871-1170

UTAH 2890 South Main Street Salt Lake City 84115 Tel: (801) 486-8166 TWX: 910-925-5681

VIRGINIA P.O. Box 6514 2111 Spencer Road Richmond 23230 Tel: (703) 282-5451 TWX: 710-956-0157

WASHINGTON 433-108th N.E. Bellevue 98004 Tel: (206) 454-3971 TWX: 910-443-2303

FOR U.S. AREAS NOT FOR U.S. AREAS NOT LISTED: Contact the regional office near-est you: Atlanta, Georgia. North Hollywood, California... Paramus, New Jersey .. Skokie, Illinois. Their complete ad-dresses are listed above.

CANADA

ALBERTA Hewlett-Packard (Canada) Ltd. 11745 Jasper Ave. Edmonton Tel: (403) 482-5561 TWX: 610-831-2431

BRITISH COLUMBIA Hewlett-Packard (Canada) Ltd. 304-1037 West Broadway Vancouver 9 Tel: (604) 738-5301 TWX: 610-922-5059

Hewlett-Packard (Canada) Ltd. 511 Bradford Ct. St. James Tel: (204) 786-7581

NOVA SCOTIA Hewlett-Packard (Canada) Ltd. 2745 Dutch Village Rd. Suite 203 Halifax Tel: (902) 455-0511 TWX: 610-271-4482

ONTARIO ONTARIO
Hewlett-Packard (Canada) Ltd.
880 Lady Ellen Place
Ottawa 3
Tel: (613) 722-4223
TWX: 610-562-1952

Hewlett-Packard (Canada) Ltd. 1415 Lawrence Avenue West Toronto Tel: (416) 249-9196 TWX: 610-492-2382

QUEBEC Hewlett-Packard (Canada) Ltd. 275 Hymus Boulevard Pointe Claire Tel: (514) 697-4232 TWX: 610-422-3022 Telex: 01-20607

FOR CANADIAN AREAS NOT Contact Hewlett-Packard (Can-ada) Ltd. in Pointe Claire, at the complete address listed above.

CENTRAL AND SOUTH AMERICA

ARGENTINA Hewlett-Packard Argentina S.A.C.e.I Lavalle 1171 - 3° Lavaile 11/1-3 Stado 213 - Officina Santiago Tel: 35-0436, 35-0627, 35-0431 Tel: 31-890, 490-505 Telex: 012-1009 Cable: HEWPACKARG COLOMBIA

BRAZIL Hewlett-Packard Do Brasil I.e.C Ltda. Rua Coronel: Oscar Porto, 691 Sao Paulo - 8, SP Tel: 71-1503 Cable: HEWPACK Sao Paulo

Hewlett-Packard Do Brasil I.e.C. Ltda. Avenida Franklin Roosevelt 84-Rio de Janeiro, ZC-39, GB Tel: 32-9733 Cable: HEWPACK Rio de Janeiro CHILE Hector Calcagni P. Casilla 13942 Estado 215 - Oficina 1016

Instrumentacion Henrik A. Langebaek & Kier Ltda.
Carrera 7 #48-59
Apartado Aereo 6287
Bogota, 1 D.E.
Tel: 45-78-06, 45-55-46
Cable: AARIS Bogota

COSTA RICA Lic. Alfredo Gallegos Gurdián Apartado 3243 San José Tel: 21-86-13 Cable: GALGUR San José

ECUADOR Laboratorios de Radio-Ingenieria Calle Guayaquil 1246 Post Office Box 3199 Quito Tel: 12496 Cable: HORVATH Quito

EL SALVADOR Electrónica
Apartado Postal 1589
27 Avenida Norte 1133
San Salvador
Tel: 25-74-50
Cable: ELECTRONICA
San Salvador

GUATEMALA Olander Associates Latin America Apartado 1226 7a. Calle, 0-22, Zona 1 Guatemala City

MEXICO MEXICO Hewlett-Packard Mexicana, S.A. de C.V. Moras 439 Col. del Valle Mexico 12, D.F. Tel: 75-46-49

NICARAGUA Roberto Terán G. Apartado Postal 689 Edificio Terán Managua Tel: 3451, 3452 Cable: ROTERAN Managua

PANAMA Electrónica Balboa, S.A. P.O. Box 4929 Ave. Manuel Espinosa No. 13-50 Bldg. Alina Panama City Tel: 30833 Cable: ELECTRON Panama City

PERII Fernando Ezeta B. Avenida Petit Thouars 4719 Miraflores Casilla 3061 Lima Tel: 50346 Cable: FEPERU Lima

PUERTO RICO PUERTO RICO San Juan Electronics, Inc. P.O. Box 5167 Ponce de Leon 154 Pda. 3-Pta. de Tierra Tel: (809) 725-3342 Cable: SATRONICS San Juan Telex: SATRON 3450 332

URUGUAY Pablo Ferrando S.A. Comercial e Industrial Avenida Italia 2877 Casilla de Correo 370 Montevideo Tel: 40-3102 Cable: RADIUM Montevideo VENEZUELA Hewlett-Packard De Venezuela C.A. C.A. Apartado del Este 10934 Chacaito Caracas Tel: 71.88.05, 71.88.69, 71.88.76 Cable: HEWPACK Caracas

FOR AREAS NOT LISTED, CONTACT:
Hewlett-Packard Inter-Americas
3200 Hillview Ave.
Pale Alte, California 94304
Tel: (415) 326-7000
TWX: 910-373-1267
Cable: HEWPACK Pale Alto
Telex: 034-8461

EUROPE

AUSTRIA
Unilabor GmbH
Wissenschaftliche Instrumente
Rummelhardtgasse 6/3
P.O. Box 33
Vienna A-1095
Tel: 42 61 81
Cable: LABORINSTRUMENT
Vienna Vienna Telex: 75 762

BELGIUM Hewlett-Packard Benelux S.A. 348 Boulevard du Souverain Brussels 16 Tel: 72 22 40 Cable: PALOBEN Brussels Telex: 23 494

DENMARK DENMARK
Hewlett-Packard A/S
Langebjerg 6
2850 Naerum
Tel: (01) 80 40 40
Cable: HEWPACK AS
Telex: 66 40

FINLAND Hewlett-Packard Oy Gyldenintie 3 Helsinki 20 Tel: 67 35 38 Cable: HEWPACKOY-Helsinki Telex: 12-1563 FRANCE Hewlett-Packard France Quartier de Courtaboeuf Boite Postale No. 6 91 Orsay Tel: 920 88 01 Cable: HEWPACK Orsay Telex: 60048 HEWPACK ORSAY

Hewlett-Packard France Hewlett-Packard France 4 Quai des Etroits 69 Lyon 5e Tel: 42 63 45 Cable: HEWPACK Lyon Telex: 31617

GERMANY Hewlett-Packard Vertriebs-GmbH Lietzenburgerstrasse 30 1 Berlin W 30 . Tel: 24 60 65/66 Telex: 18 34 05

Hewlett-Packard Vertriebs-GmbH Herrenbergerstrasse 110 703 Böblingen, Württemberg Tel: 07031-6671 Cable: HEPAG Böblingen

Telex: 72 65 739 Hewlett-Packard Vertriebs-GmbH Achenbachstrasse 15 4 **Düsseldorf** 1 Tel: 68 52 58/59 Telex: 85 86 533 Hewlett-Packard Vertriebs-GmbH Kurhessenstrasse 95 6 Frankfurt 50 Tel: 52 00 36 Cable: HEWPACKSA Frankfurt Telex: 41 32 49

Hewlett-Packard Vertriebs-GmbH Reginfriedstrasse 13 Regimmedstrasse 13 8 München 9 Tel: 0811 69 59 71/75 Cable: HEWPACKSA München Telex: 52 49 85

Kostas Karavannis ROSTAS KATAYANNIS 18, Ermou Street Athens 126 Tel: 230 301 Cable: RAKAR Athens Telex: 21 59 62

IRELAND IRELAND Hewlett-Packard Ltd. 224 Bath Road Slough, Bucks, England Tel: Slough 753-33341 Cable: HEWPIE Slough Telex: 84413

ITALY
Hewlett-Packard Italiana S.p.A.
Viale Lunigiana 46
20125 Milan
Tel: 69 15 84
Cable: HEWPACKIT Milan
Telex: 32046

Hewlett-Packard Vertriebs-GmbH
Belm Strohhause 26 Palazzo Italia
2 Hamburg 1 Plazza Marconi 25
Tel: 24 05 51/52 00144 Rome - Eur
Cable: HEWPACKSA Hamburg
Telex: 22 53 32
Chewlett-Packard Vertriebs-GmbH
Telex: 61514

NETHERLANDS Hewlett-Packard Benelux, N.V. Weederstein 117 Amsterdam, Z II Tel: 42 77 77 Cable: PALOBEN Amsterdam Telex: 13 216

NORWAY Hewlett-Packard Norge A/S Box 149 Nesveien 13 Haslum Tel: 53 83 60 Cable: HEWPACK Oslo Telex: 6621

PORTUGAL Telectra Rua Rodrigo da Fonseca 103 P.O. Box 2531 P.O. Box 2531 Lisbon 1 Tel: 68 60 72 Cable: TELECTRA Lisbon Telex: 1598

SPAIN Ataio Ingenieros Ganduxer 76 Barcelona 6 Tel: 211-44-66 Tel: 211-44-05
Ataio Ingenieros
Enrique Larreta 12
Madrid, 16
Tel: 235 43 44
Cable: TELEATAIO Madrid
Telex: 2 72 49

SWEDEN Hewlett-Packard (Sverige) AB Hagakersgatan 9C 431 04 Mölndal 4 Tel: 031 - 27 68 00 Hewlett-Packard (Sverige) AB Svetsarvägen 7 S171 20 Solna 1 Tel: (08) 98 12 50 Cable: MEASUREMENTS Stockholm Telex: 10721

SWITZERLAND Hewlett Packard (Schweitz) AG Zurcherstrasse 20 8952 Schlieren Tel: (051) 98 18 21/24
Cable: HEWPACKAG Zurich
Telex: 53933

Hewlett Packard (Schweitz) A.G. Reve du Bois-du-Lan 7 1217 Meyrin-Geneva Tel: (022) 41 54 00 Cable: HEWPACKSA Geneva Telex: 2 24 86

TURKEY
Telekom Engineering Bureau
P.O. Box 376 - Galata
Istanbul
Tel: 49 40 40
Cable: TELEMATION Istanbul

UNITED KINGDOM Hewlett-Packard Ltd. 224 Bath Road Slough, Bucks Tel: Slough 753-33341 Cable: HEWPIE Slough Telex: 84413

VIIGOSI AVIA YUGOSLAVIA Beiram S.A. 83 avenue des Mimosas Brussels 15, Belgium Tel: 34 33 32, 34 26 19 Cable: BELRAMEL Brussels Telex: 21790

FOR AREAS NOT LISTED. CONTACT: Hewlett-Packard S.A. Rue du Bois-du-Lan 7 1217 Meyrin-Geneva Tel: (022) 41 54 00 Cable: HEWPACKSA Geneva Telex: 2.24.86

AFRICA, ASIA, AUSTRALIA

ANGOLA
Telectra Empresa Técnica
de Equipamentos Eléctricos
SAR Rua de Barbosa Rodrigues 42-1°

Box 6487 Luanda Cable: TELECTRA Luanda AUSTRALIA Hewlett-Packard Australia Pty. Ltd. 22-26 Weir Street Glen Iris, 3166 Victoria Tel: 20.1371 (4 lines) Cable: HEWPARD Melbourne Telex: 31024 AUSTRALIA

Hewlett-Packard Australia Hewlett-Packard Australia
Pty. Ltd.
61 Alexander Street
Crows Nest 2065
New South Wales
Tel: 43.7866
Cable: HEWPARD Sydney

Hewlett-Packard Australia Pty. Ltd. 97 Churchill Road Prospect 5082 South Australia Tel: 65.2366 Cable: HEWPARD Adelaide

Hewlett Packard Australia Pty. Ltd.
2nd Floor, Suite 13
Casablanca Buildings
196 Adelaide Terrace
Perth, W.A. 6000

CEYLON United Electricals Ltd. P.O. Box 681 Yahala Building Staples Street
Colombo 2
Tel: 5496
Cable: HOTPOINT Colombo CYPRUS Kypronics 19-19D Hommer Avenue P.O. Box 752

Nicosia Tel: 6282-75628 Cable: HE-I-NAMI

African Salespower & Agency Private Ltd., Co. P. O. Box 718 58/59 Cunningham St. Addis Ababa Tel: 12285 Cable: ASACO Addisababa

HONG KONG P.O. Box 297 1511, Prince's Building 10, Chater Road Hong Kong Tel: 240168, 232735 Cable: SCHMIDTCO Hong Kong

INDIA
The Scientific Instrument
Co., Ld.
6, Tej Bahadur Sapru Road
Allahabad
Tel: 2451
Cable: SICO Allahbad

The Scientific Instrument Co., Ld. 240, Dr. Dadabhai Naoroji Road Bombay 1 Tel: 26-2642 Cable: SICO Bombay The Scientific Instrument

Co., Ld. 11. Esplanade East Calcutta 1 Tel: 23-4129 Cable: SICO Calcutta The Scientific Instrument Co., Ld. 30, Mount Road Madras 2 Tel: 86339 Cable: SICO Madras

Tel: 27-1053 Cable: SICO New Delhi

INDONESIA Bah Bolon Trading Coy. N.V. Djalah Merdeka 29 Bandung

IRAN Telecom, Ltd.
P. O. Box 1812
240 Kh. Saba Shomali
Teheran
Tel: 43850, 48111
Cable: BASCOM Teheran

ISRAEL
Electronics & Engineering
Div. of Motorola Israel Ltd.
16, Kremenetski Street
Tel-Aviv
Tel: 35021 (4 lines)
Cable: BASTEL Tel-Aviv
Telex: Bastel Tv 033-569

Yokogawa-Hewlett-Packard Ltd. Nisei Ibaragi Bldg. 2-2-8 Kasuga Ibaragi-Shi

Osaka Tel: 23-1641 Yokogawa-Hewlett-Packard Ltd. Ito Building No. 59, Kotori-cho Nakamura-ku, Nagoya City Tel: 551-0215

Yokogawa-Hewlett-Packard Ltd. Ohashi Building Shibuya-ku, Tokyo Tel: 370-2281 Telex: 232-2024YHP Cable: YHPMARKET TOK 23-724

The Scientific Instrument Co. Ltd.
5-8-525 Mahatama Gandhi Road
Hydferabad 1. (A-P) India
Cable: SICO Hyderabad
Cable: SICO Hyderabad
The Scientific Instrument Co., Ld.
PA, Ajmeri Gate Extn.
New Delhi 1
Tel: 27-1053
Cable: ARIVITEE Mairobi
Cable: ARIVITEE Mairobi

KOREA American Trading Co., Korea, Ltd. P.O. Box 1103 Dae Kyung Bidg. 107 Sejong Ro Chongro Ku Seoul Tel: 75-5841 (4 lines) Cable: AMTRACO Seoul

KOREA

LEBANON Constantin E. Macridis Clemenceau Street Clemenceau Center Beirut Tel: 220846 Cable: ELECTRONUCLEAR Beirut

MALAYSIA Section 13

Petaling Jaya, Selangor
Cable: MECOMB Kuala Lumpur

MOZAMBIQUE
A. N. Goncalves, LDA.
4.1 Apt. 14 Av. D. Luis
P.O. Box 107
Lourenco Marques
Cable: NEGON NEW ZEALAND

NEW ZEALAND Hewlett-Packard (N.Z.) Ltd. 32-34 Kent Terrace P.O. Box 9443 Wellington, N.Z. Tel: 55-409 Cable: HEWPACK Wellington

PAKISTAN (EAST) Mushko & Company, Ltd. 31, Jinnah Avenue Dacca Tel: 80058 Cable: NEWDEAL Dacca

PAKISTAN (WEST) Mushko & Company, Ltd. Oosman Chambers Victoria Road Karachi 3 Tel: 51027, 52927 Cable: COOPERATOR Karachi

PHILIPPINES
Electromex Inc.
2129 Pasong Tamo
Makati, Rizal
P.O. Box 4326
Manila Tel: 88-91-71 or 88-83-76 Cable: ELEMEX Manila

Capie: ELEMEX Manifa

SINGAPORE
Mechanical and Combustion
Engineering Company Ltd.
9, Jalan Kilang
Singapore, 3

Tel: 642361-3

Cable: MECOMB Singapore SOUTH AFRICA

Hewlett Packard South Africa (Pty.), Ltd. Hill House 43 Somerset Rd. 43 Somerset Rd.
Cape Town
Tel: 3-6019
Cable: HEWPACK Cape Town
Telex: 7038CT Hewlett Packard South Africa (Pty.), Ltd. P.O. Box 31716 30 De Beer Street

Braamfontein, Johannesburg Tel: 724-4172 724-4195 Telex: 0226 JH Cable: HEWPACK Johannesburg TAIWAN TAIWAN Hwa Sheng Electronic Co., Ltd. P. O. Box 1558 Room 404 Chia Hsin Building No. 96 Chung Shan North Road, Sec. 2

Talpei
Tel: 555211 Ext. 532-539
Cable: VICTRONIX Talpei

TANZANIA R. J. Tilbury Ltd. P.O. Box 2754 Suite 517/518 Hotel Ambassade Tel: 25670, 26803, 68206, 58196 Cable: ARJAYTEE Nairobi

THAILAND The International Engineering Co., Ltd. P. O. Box 39 P. O. Box 39 614 Sukhumvit Road Bangkok Tel: 910722 (7 lines) Cable: GYSOM Bangkok

LIGANDA Hotel Ambassadeur Nairobi NairODI Tel: 25670, 26803, 68206, 58196 Cable: ARJAYTEE Nairobi

VIETNAM Peninsular Trading Inc. P.O. Box H-3 216 Hien-Vuong Saigon Tel: 20.805 Cable: PENINSULA Saigon

ZAMBIA R. J. Tilbury (Zambia) Ltd. P.O. Box 2792 Lusaka Zambia, Central Africa

FOR AREAS NOT LISTED FOR AREAS NOT LISTEI CONTACT: Hewlett-Packard Export Marketing 3200 Hillview Ave. Palo Alto, California 94304 Tel: (415) 326-7000 TWX: 910-373-1267 Cable: HEWPACK Palo Alto Telex: 034-8461

Printed in U.S.A. 30M-11/68



120B-903 PRINTED IN U.S.A.